



**LICHFIELD
FIRE & SAFETY
EQUIPMENT
CO. LTD.**

LIFECO-01

**ENGINEERED CLEAN AGENT
INERT GAS FIRE SUPPRESSION SYSTEM**

**DESIGN, INSTALLATION, OPERATION AND
MAINTENANCE MANUAL**

**LICHFIELD FIRE & SAFETY EQUIPMENT CO LTD
EDMUND HOUSE
12-22 NEWHALL STREET
BIRMINGHAM, B3 3AS
UNITED KINGDOM**

TABLE OF CONTENTS

| | |
|---|----|
| FOREWORD | v |
| 1.0 INTRODUCTION | 1 |
| 1.1 AGENT | 1 |
| 1.2 PHYSICAL PROPERTIES AGENT | 2 |
| 1.3 PRODUCT SPECIFICATIONS | 2 |
| 1.4 SAFETY CONSIDERATIONS | 3 |
| 2.0 IG SYSTEM COMPONENTS | 5 |
| 2.1 IG CYLINDER ASSEMBLY | 5 |
| 2.2 VALVE ASSEMBLY | 7 |
| 2.3 PILOT ASSEMBLY | 9 |
| 2.4 PILOT CYLINDER BRACKET | 10 |
| 2.5 CYLINDER BRACKET | 11 |
| 2.6 PRESSURE GAUGE | 12 |
| 2.7 MANUAL ACTUATOR | 13 |
| 2.8 PNEUMATIC ACTUATOR | 14 |
| 2.9 PNEUMATIC MANUAL ACTUATOR | 15 |
| 2.10 DISCHARGE HOSE | 16 |
| 2.11 CONSTANT PRESSURE REGULATOR | 17 |
| 2.12 FLEXIBLE HOSE | 18 |
| 2.13 BLEED VALVE | 19 |
| 2.14 CHECK VALVES | 20 |

| | | |
|-------------|---|----|
| 2.15 | DISCHARGE NOZZLES | 21 |
| 2.16 | SELECTOR VALVE | 23 |
| 2.17 | PILOT HOSE FITTING ADAPTOR | 25 |
| 2.18 | PILOT VALVE ADAPTOR | 26 |
| 2.19 | PILOT LINE CHECK VALVE | 27 |
| 2.20 | CYLINDER LABEL | 28 |
| 2.21 | MANIFOLDS | 29 |
| 2.22 | DISCHARGE PRESSURE SWITCH | 31 |
| 3.0 | SYSTEM DESIGN | 32 |
| 3.1 | ENCLOSURE DATA | 32 |
| 3.2 | LIFECO-01 DESIGN CONCENTRATIONS | 33 |
| 3.3 | INERT GAS AGENT CALCULATION EQUATION | 35 |
| 3.4 | VENTING REQUIREMENTS | 36 |
| 3.5 | ENGINEERED SYSTEMS | 36 |
| 3.6 | PIPE & FLOW LIMITATIONS | 37 |
| 3.7 | TEE LIMITATIONS | 39 |
| 3.8 | DISCHARGE TIME | 42 |
| 3.9 | AGENT STORAGE CYLINDER | 42 |
| 3.10 | MANIFOLDS / PIPING | 42 |
| 3.11 | DISCHARGE NOZZLE | 43 |
| 3.12 | AGENT CALCULATION SAMPLE | 44 |
| 4.0 | SYSTEMS MECHANICAL INSTALLATION | 46 |
| 4.1 | PIPE INSTALLATION | 49 |
| 4.2 | ACTUATION INSTALLATION | 50 |

| | | |
|-------------|---|-----------|
| 4.3 | INSTALLATION OF SELECTOR VALVE..... | 54 |
| 4.4 | DETECTION OF CONTROL EQUIPMENT | 55 |
| 4.5 | INSTALLATION OF DISCHARGE PRESSURE SWITCH | 56 |
| 5.0 | INSPECTION OF SYSTEM AFTER INSTALLATION | 58 |
| 6.0 | MAINTENANCE..... | 60 |
| 6.2 | SEMI-ANNUALLY PREVENTIVE MAINTENANCE PROCEDURES | 61 |
| 6.3 | EVERY TWO YEARS PREVENTIVE MAINTENANCE PROCEDURES | 62 |
| 7.0 | SYSTEM DISCHARGE - RECHARGING CYLINDER AFTER OPERATION | 63 |
| 7.1 | FILLING INERT GAS AGENT..... | 64 |
| 7.2 | FILLING INFORMATION..... | 65 |
| 8.0 | WARRANTY..... | 66 |
| 9.0 | DISCLAIMERS | 67 |
| 10.0 | APPENDICES | 68 |

FOREWORD

This manual LFIGMAL-0001 is a comprehensive guide that comprises all the information that need to install, design and maintain IG-01 fire suppression systems manufactured by LIFECO.

LIFECO-01 Engineered total flooding fire suppression systems shall be designed, inspected, tested, maintained and recharged by qualified and trained personnel in accordance with requirement as follow:

- National Fire Protection Association 2001 (NFPA 2001) “Standard on Clean Agent Fire Extinguishing Systems”.
- UL 2127 Standard for Safety Inert Gas Clean Agent Extinguishing System Units.
- FM 5600 Approval Standard for Clean Agent Extinguishing Systems
- All guidelines, limitations etc included in this manual P/N: LFIGMAL-0001.
- Local Authority having jurisdiction.

DENOTATIONS

System

The text “system” in this manual refers to the fire suppression components and does not cover fire alarm and detection system which may trigger an agent discharge.

Engineered

Hydraulic flow program used to predict the flow of Inert Gas through a pipe network.

IG-01

Inert Gas IG-01 is a clean agent fire suppression system using an inert gas consisting of 100% Argon.

The following written remarks are used throughout this manual. They are important to the safe use of the Component described in this manual.

WARNING:

The instructions indicated under these remarks, which if not correctly adhered, could result in severe injury or death.

CAUTION:

The instructions indicated under these remarks, which if not correctly adhered, could result in minor injury or death.

IMPORTANT

This information is the property of LIFECO. who reserves the right to make any alteration without prior notice. No reproduction, modification, totals or partial translation is allowed for any purpose than internal use. Every effort has been made to ensure accuracy of information contained herein, however, LIFECO disclaims any liability or damage caused that may be made from the use of the data and information contained herein by any other party. Anyone using the data and information contained in this manual does so under his/her own responsibility and takes whatever consequence he/she may encounters.

Any questions concerning the information presented in this manual should be addressed to: -

LICHFIELD FIRE & SAFETY EQUIPMENT CO LTD

Edmund House

12-22 Newhall Street

Birmingham, B3 3AS

United Kingdom

Tel: +44 (0) 1902 798 706

Fax: +44 (0) 1902 798 679

E-mail: sales@lifeco-uk.com

1.0 INTRODUCTION

LIFECO-01 Engineered Fire Suppression systems are Underwriters Laboratories Inc. (UL) listed and Factory Mutual (FM) Approved. These systems are designed for total flooding in accordance with NFPA 2001 "Standard on Clean Agent Fire Extinguishing Systems", UL 2127 Standard for Safety Inert Gas Clean Agent Extinguishing System Units and FM 5600 Approval Standard for Clean Agent Extinguishing Systems. In any situation not specifically covered by this manual, the application and installation of the system must meet the requirements of the standard as stated or Local Authority Having Jurisdiction.

1.1 AGENT

LIFECO-01 Engineered Fire Suppression systems consist of inert gas extinguishing agent: IG-01 (100% Argon)

Inert gas is a colorless, odorless, electrically non-conductive gas. The gases do not support combustion, do not deplete the ozone layer and as well as no global warming potential. Inert gas is pressurized and stored in seamless cylinders assembly which hold at 200bar or 300 bar @ 15°C (2900 psi or 4351psi @ 59°F). LIFECO-01 systems are ideal for total flooding applications to suppress Class A, B and C hazards. The main extinguishing mechanism of inert gas is by lowering the oxygen content below the level that supports combustion.

IG-01 is listed under;

- i. National Fire Protection Agency (NFPA®) 2001, Standard on Clean Agent Fire Extinguishing Systems.
- ii. Underwriters Laboratories (UL)
- iii. FM (Factory Mutual) Approved
- iv. U.S. Environmental Protection Agency

1.2 PHYSICAL PROPERTIES AGENT

Table 1.0 Physical Properties of IG-01

| Physical Properties | IG-01 |
|-----------------------------------|-----------------------|
| Chemical Name | Argon |
| Molecular Weight | 39.9 g/mol |
| Boiling Point @ 1 atm (1.013 bar) | -185.9 °C (-302.6 °F) |
| Critical Pressure | 4900kPa |
| Critical Temperature | -122.3 °C (-188.1 °F) |
| Ozone Depleting Potential | 0 |
| Global Warming Potential | 0 |

1.3 PRODUCT SPECIFICATIONS

Inert gas shall comply with the specification shown in Table 1.3.1.

Table 1.3.1 Inert Gas Quality Requirements

| Agent | Composition, by volume | Water content, by weight |
|-------|------------------------|--------------------------|
| | Argon | |
| IG-01 | Min 99.9% | 0.005% (max) |

1.4 SAFETY CONSIDERATIONS

LIFECO-01 Engineered Total Flooding Fire Suppression Systems shall not be used for fires which involving the following materials such as:

Table 1.4.1 – Limitation of Use

- Certain chemicals or mixtures of chemicals such as cellulose nitrate and gunpowder, which are capable of rapid oxidation in the absence of air.
- Reactive metals such as lithium, sodium, potassium, magnesium, titanium, zirconium, uranium and plutonium
- Metal hydrides
- Chemicals capable of undergoing auto-thermal decomposition such as certain organic peroxides and hydrazine.

Based on NFPA 2001, Inert gas concentration are specified by “No Observable Adverse Effect Level” (NOAEL) and “Lowest Observed Adverse Effect Level” (LOAEL).

Note: NOAEL is the highest concentration that no adverse physiological or toxicological effect has been observed.

LOAEL is the lowest concentration, which an adverse physiological or toxicological effect

Table 1.4.2 Inert Gas NOAEL and LOAEL Values

| Description | Concentration (% v/v) |
|--|-----------------------|
| No Observable Adverse Effect Level (NOAEL) | 43 |
| Lowest Observed Adverse Effect Level (LOAEL) | 52 |



WARNING

Do not stand directly in front of the discharge line as the high pressure discharged from the nozzles can create noise loud enough to startle occupants. The high velocity discharge of this agent can be enough to dislodge objects located directly in the discharge path. Turbulence may be created in the enclosure which capable to move the lighter objects and unsecured paper. Direct contact with the vaporizing agent discharged from the nozzles will leave a strong chilling effect on objects and can cause frostbite burns to the skin. The liquid phase vaporizes rapidly when mixed with air and limits the chilling hazard to the immediate vicinity of the nozzle. Although inert gas is colorless, discharge in humid atmospheres may cause a reduction of visibility for a short time due to the condensation of water vapor.



WARNING

When inert gas is discharged, the vaporizing inert gas discharge mixture will have a significant cooling effect which could cause skin irritation. Unnecessary exposure of personnel either to the natural form of clean agent or to the products of decomposition shall be avoided.

Emergency Aid

Refer to the Inert gas SDS within Appendix A.

Consult: LICHFIELD FIRE & SAFETY EQUIPMENT CO LTD

Emergency telephone number: +44 (0) 1902 798 706

Fax: +44 (0) 1902 798 679

E-mail: sales@lifeco-uk.com

2.0 IG SYSTEM COMPONENTS

LIFECO-01 Engineered Systems are intended to be designed and installed to suppress fire within the limitation mentioned in this manual. The systems described in this manual are FM approved and Underwriters Laboratories (UL) Listed. It is complied in accordance with UL 2127 and FM 5600.

2.1 IG CYLINDER ASSEMBLY

The cylinder assembly comprises of a cylinder factory fitted with a valve, filled with IG-01 and pressurized to 200 Bar or 300 Bar @ 15°C (2900 psi or 4351 psi @ 59°F). Cylinders are available in 80L or 140L. All these cylinders are manufactured in accordance with ISO-9809. Cylinder color is RAL3001.

Table 2.1.1 ISO Cylinders Dimension

| Size (L) | Working Pressure | Test Pressure | Height (mm), A | Height (mm), B | Cylinder Diameter (mm), C | Nominal Tare Weight (kg) |
|-------------|---------------------|------------------|-------------------|-------------------|---------------------------------|-----------------------------------|
| 80 | 200 Bar | 300 Bar | 1840-1855 | 1775 | 267 | 92 |
| 140 | | | 1800-1820 | 1735 | 356 | 146 |
| 80 | 300 Bar | 450 Bar | 1870-1885 | 1805 | 267 | 110 |
| 140 | | | 1920-1940 | 1855 | 356 | 226 |




Figure 2.1.1 Cylinder Assembly

The filled and pressurized cylinder chosen location should protect against direct sunlight, mechanical, chemical or other types of damage. The suppression systems temperature limit from -20°C (-4°F) to 55°C (131°F).

Table 2.1.3 Cylinder Details

| Agent | Size | Working Pressure | Part Number | Valve Type | Agent Quantity | | Gross Weight (kg) | |
|-------|------|------------------|------------------------|-----------------|-------------------|-------|-------------------|--|
| | | | | | (m ³) | (kg) | | |
| IG-01 | 80 | 200 Bar | LF-IG00180200S | Solenoid Valve | 17.07 | 28.28 | 120 | |
| | | | LF-IG00180200 | Discharge Valve | | | | |
| | 140 | | LF-IG001140200S | Solenoid Valve | 29.87 | 49.49 | 195 | |
| | | | LF-IG001140200 | Discharge Valve | | | | |
| | 80 | 300 Bar | LF-IG00180300S | Solenoid Valve | 24.68 | 40.9 | 151 | |
| | | | LF-IG00180300 | Discharge Valve | | | | |
| | 140 | | LF-IG001140300S | Solenoid Valve | 43.2 | 71.57 | 297 | |
| | | | LF-IG001140300 | Discharge Valve | | | | |

2.2 VALVE ASSEMBLY

Valve operates by means of pressure differential piston. The valves incorporated with the features to enable it to be connected with manual and pneumatic actuator for actuation purpose. Each valve is provided with an anti-recoil cap. Only removed when connecting cylinder to pipework and refit when disconnecting the cylinder from pipework. There are 2 types of valves:

- 1) Discharge valve
- 2) Solenoid discharge valve



Figure 2.2.1 Discharge Valve

Table 2.2.1 Discharge Valve Technical Information

| Description | Valve Size | |
|-----------------------------|-------------------|--------------------|
| Working Pressure | 200 Bar | 300 Bar |
| Part Number | LF-IGDV200 | LF-IGDV300 |
| Outlet | W21.8 x 1/14" | |
| Material | Brass | |
| Test Pressure | 360 Bar | |
| Safety Disc Pressure | 270 Bar (3916psi) | 405 Bar (5874 psi) |
| Gauge Port | M12 x 1.0 | |
| Equivalent Length | 25.84m | |
| Weight | 1.16kg | |



Figure 2.2.2 Solenoid Valve

Table 2.2.2 Solenoid Valve Technical Information

| Description | Valve Size | |
|-----------------------------|-------------------|--------------------|
| Working Pressure | 200 Bar | 300 Bar |
| Part Number | LF-IGEASV200 | LF-IGEASV300 |
| Outlet | W21.8 x 1/14" | |
| Material | Brass | |
| Test Pressure | 360 Bar | |
| Safety Disc Pressure | 270 Bar (3916psi) | 405 Bar (5874 psi) |
| Gauge Port | M12 x 1.0 | |
| Equivalent Length | 25.84m | |
| Weight | 1.55kg | |
| Voltage | 24 VDC | |
| Max Current | 0.4 A | |
| Power consumption | 9.3 W | |
| Protection class | IP65 | |

2.3 PILOT ASSEMBLY

The cylinder assembly comprises of a cylinder factory fitted with a solenoid discharge valve (PN: LFIGEASV200), filled with nitrogen and pressurized to 200 Bar @ 15°C (2900 psi @ 59°F). Cylinders are available in 4L and 10L. Pilot assembly is to actuate cylinders pneumatically in a system and selector valve if system available. Pilot valve adaptor (PN: LF-PVA) is available to adapt the pilot cylinder to the pilot line. (*4L is not FM approved)

Table 2.3.1 Pilot Cylinder Technical Information

| Description | Specification | |
|-------------------------------|-------------------|-----------|
| Working Pressure | 200 Bar @ 15°C | |
| Size | 4L | 10 L |
| Part Number (ISO 9809) | LF-IGPC4 | LF-IGPC10 |
| Outlet | W21.8 x 1/14" | |
| Test Pressure | 300 Bar | |
| Safety Disc Pressure | 270 Bar (3916psi) | |
| Gauge Port | M12 x 1.0 | |
| Equivalent Length | 25.84m | |
| Weight | 10kg | 19kg |
| Voltage | 24 VDC | |
| Max Current | 0.4 A | |
| Power consumption | 9.3 W | |
| Protection class | IP65 | |
| Overall height | 500mm | 950mm |
| Cylinder diameter | 140mm | |



Figure 2.3.1 Pilot Cylinder Assembly

2.4 PILOT CYLINDER BRACKET

Pilot cylinder bracket designed to mount 4L and 10L Pilot cylinder to the wall. Pilot cylinder bracket features 2 strap design to give flexibility for adjustable height.




Figure 2.4.1 Pilot Cylinder Bracket

Table 2.4.1 Pilot Cylinder Bracket Technical Information

| Description | Specification |
|--------------------|------------------------------|
| Part Number | LF- CBP |
| Material | Mild Steel |
| Paint | Epoxy Powder Coating (Black) |
| Mounting | Wall |

2.5 CYLINDER BRACKET

Cylinder brackets are available for 80L(200bar/300bar) and 140L(200bar/300bar) cylinders. It comes with an unistrut channel designed to securely fix the cylinders to a supporting structure or wall. Cylinder to be floor mounted only.




Figure 2.5.1 Cylinder Bracket

Table 2.5.1 Cylinder Bracket Technical Information

| Description | Specification |
|-----------------|------------------------------|
| Material | Mild Steel |
| Paint | Epoxy Powder Coating (Black) |
| Mounting | Unistrut Channel |

| Part Number | Cylinder Size | Unistrut Channel Length | Row | Set comes with |
|-------------|------------------------|-------------------------|-------------------------------|--|
| LF- CB-80 | 80L (200bar & 300bar) | 360 mm (14.2 inch) | 1 st Row | 1x Strap, 2x M12 stud with c channel stopper, 2x washer, 2x Nut, 1x Unistrut channel |
| LF- CB-140 | 140L (200bar & 300bar) | 450 mm (17.7 inch) | | |
| LF- CBX-80 | 80L (200bar & 300bar) | N/A | 2 nd Row and above | 1x Strap, 2x M12 stud |
| LF- CBX-140 | 140L (200bar & 300bar) | N/A | | |

2.6 PRESSURE GAUGE

There are two types of pressure gauge;

- 1) Pressure gauge with switch 200 Bar
- 2) Pressure gauge with switch 300 Bar

Pressure gauge comes with electrical contact to monitor cylinder pressure and to report losses of cylinder contents. Cylinder assembly can be supply with pressure gauge with Normally Open switch or Normally Close switch. Both pressure gauge can be assembled and dissembled under pressure.




Figure 2.6.1 Pressure Gauge with switch

Table 2.6.1 Pressure Gauge Technical Information

| Description | Specification | | | | | |
|--------------------------|----------------------------|----------------------------|----------------------------|----------------------------|--|--|
| Working Pressure | 200 Bar | 300 Bar | 200 Bar | 300 Bar | | |
| Part Number | LF-PGLPS4 | LF-PGLPS3 | LF-PGLPS6 | LF-PGLPS5 | | |
| Body | Stainless Steel Case | | | | | |
| Type | Bourdon Tube | | | | | |
| Gauge Size | 50mm | | | | | |
| Pressure Range | 0 – 300 Bar (0 – 4351 psi) | 0 – 450 Bar (0 – 6527 psi) | 0 – 300 Bar (0 – 4351 psi) | 0 – 450 Bar (0 – 6527 psi) | | |
| Std. Connection | M12 x 1.0 | | | | | |
| Set Point | 180 Bar (2611 psi) | 270 Bar (3916 psi) | 180 Bar (2611 psi) | 270 Bar (3916 psi) | | |
| Switching Type | Normally Open (NO) | | Normally Close (NC) | | | |
| Switching voltage | 4.5 – 24 VDC/VAC | | | | | |
| Switching current | 5 – 100mA | | | | | |
| Contact Load | Max 2.4W | | | | | |

2.7 MANUAL ACTUATOR

The manual actuator is designed to be used and installed with solenoid valve (PN: LF-IGEASV200 & LF-IGEASV300) for mechanically actuation. Safety pin is provided with every actuator to prevent accidental discharge. Actuation by removing safety pin and moving lever to 90°. Manual actuator features retractable pin which reset when level back to original position.



Figure 2.7.1 Manual Actuator

Table 2.7.1 Manual Actuator Technical Information

| Description | Specification |
|------------------------|---------------------|
| Part Number | LF-COMA |
| Body | Brass C3604BD |
| Level | Stainless Steel |
| Safety Pin | Stainless Steel |
| Piston Rod | Brass C3604BD |
| Connection | M20 x 1.5 |
| Overall Size | 48mm (H) x 28mm (W) |
| Mounting Torque | 15 Nm ± 1 |

2.8 PNEUMATIC ACTUATOR

Pneumatic actuator is designed to be used and installed with valve (PN: LF-IGDV200 & LF-IGDV300) for pneumatically actuation. The pneumatic actuator features a pneumatically driven piston that used to depress the valve core and opening the valve. The pressure from the master cylinder is used to actuate the cylinder discharge valve of slave cylinder via flexible hose.



Figure 2.8.1 Pneumatic Actuator

Table 2.8.2 Pneumatic Actuator Technical Information

| Description | Specification |
|-----------------------------|--|
| Part Number | LF-COPA |
| Body | Brass C3604BD |
| Actuation Pin | Brass C3604BD |
| Valve Connection | M36 x 1.5 |
| Pneumatic Connection | 2 x 1/8" BSP |
| Overall Size | 56.5mm (L) x 40mm (Diameter) |
| Pilot Pressure | Min 20 Bar (290 psi), Max 360 Bar (5221 psi) |
| Mounting Torque | 25 Nm \pm 2 |

2.9 PNEUMATIC MANUAL ACTUATOR

Pneumatic Manual actuator is designed to be used and installed on valve for mechanically or pneumatically actuation.




Figure 2.9.1 Pneumatic Manual Actuator

Table 2.9.1 Pneumatic Manual Actuator Technical Information

| Description | Specification | |
|-----------------------------|---|---|
| Part Number | LF-COMPA | LF-COMPA/1 |
| Used with Valve | Discharge valve LF-IGDV200 & LF-IGDV300 | Solenoid valve LF-IGEASV200 & LF-IGEASV300 |
| Body | Brass C3604BD | |
| Actuation Pin | Brass C3604BD | |
| Valve Connection | M36 x 1.5 | M20 x 1.5 |
| Pneumatic Connection | 2 x 1/8" BSP | |
| Overall Size | 83mm (L) x 40mm (Diameter) | |
| Pilot Pressure | Min 8 Bar (116 psi), Max 300 Bar (4351 psi) | |
| Mounting Torque | 15 Nm ± 1 | |

2.10 DISCHARGE HOSE

The discharge hose is equipped with a female swivel fitting at the inlet and enable to connect the cylinders to the manifold in multiple cylinder arrangements. This feature has enables cylinder to be disconnected during maintenance without any effort to remove other manifold connection and pipework.




Figure 2.10.1 Discharge Hose

Table 2.10.1 Discharge Hose Technical Information

| Description | Specification | |
|-----------------------------|-----------------------------------|-----------|
| Part Number | LF-DH500E | LF-DH500S |
| Type | 90° Elbow | Straight |
| Hose Material | Synthetic rubber | |
| Connection Material | Coated Steel | |
| Inlet Connection | W21.8 x 1/14" | |
| Outlet Connection | 3/4" BSP | |
| Min Bend Radius | 250mm | |
| Max Working Pressure | 360 Bar (5221 psi) | |
| Temperature Range | -20°C to + 50°C (-4 °F to 122 °F) | |
| Overall Length | 500mm | |
| Size | DN12 | |

*Various length is available upon request.

2.11 CONSTANT PRESSURE REGULATOR

Constant Pressure Regulator provided constant flow throughout the discharge. It regulates the pressure to ≤ 60 Bar for 200 Bar and 300 bar system which enable a lower pressure rating piping can be used. It gives higher flow rates and achieve 95% of the discharge within 60 seconds.



Figure 2.11.1 Constant Pressure Regulator

Table 2.11.1 Constant Pressure Regulator Technical Information

| Description | Specification |
|--------------------------|--|
| Part Number | LF-PR |
| Material | Brass |
| Inlet Connection | 3/4" BSP Female |
| Outlet Connection | 3/4" BSP Male |
| Inlet Pressure | Max 360 Bar (5221 psi) |
| Outlet Pressure | Static: 60 Bar (+2, -6 Bar), 870 psi (-29, +87 psi) Dynamic: Max 60 Bar (870 psi) |
| Overall Size | 145mm (L) x 64mm (Diameter) |
| Mounting Torque | 55 Nm \pm 5 |

2.12 FLEXIBLE HOSE

The flexible hose is used to connect between the master cylinder valve port and slave cylinder pneumatic actuator and slave to slave cylinder pneumatic actuator. This flexible hose is act as a pressure connector.




Figure 2.12.1 Flexible Hose

Table 2.12.1 Flexible Hose Technical Information

| Description | Specification | |
|-----------------------------|-----------------------------------|----------|
| Part Number | LF-PH350 | LF-PH450 |
| Hose Material | Synthetic rubber | |
| Connection Material | Coated Steel | |
| Connection | M12 x 1.5 | |
| Min Bend Radius | 30mm | |
| Max Working Pressure | 360 Bar (5221 psi) | |
| Temperature Range | -20°C to + 65°C (-4 °F to 149 °F) | |
| Overall Length | 350mm (L) | 450mm(L) |
| Size | DN5 | |

*Various length is available upon request.

2.13 BLEED VALVE

Bleed valve is used and installed in pneumatic pilot lines to prevent and release unintended pressure developed in the pilot line.



Figure 2.13.1 Bleed Valve

Figure 2.13.1 Bleed Valve Technical Information

| Description | Specification |
|-----------------------------|--|
| Part Number | LF-BVPL |
| Material | Stainless Steel |
| Connection | 1/8" BSP |
| Max Working Pressure | 360 Bar (5221 psi) |
| Temperature Range | -20°C to + 65°C (-4 °F to 149 °F) |
| Overall Size | 64mm (L) x 22mm (W) |
| Pressure | Closing : 0.4 Bar Increasing Pressure Opening: 0.5 Bar Falling Pressure |

2.14 CHECK VALVES

Check valve is connected between discharge hose and constant pressure regulator before the manifold to prevent backflow of the agent during a discharge.




Figure 2.14.1 Check Valve

Table 2.14.1 Check Valve Technical Information

| Description | Specification |
|-------------------|---------------------|
| Part Number | LF-CV |
| Nominal Size | 12mm |
| Material | Stainless Steel |
| Connection | 3/4" BSP Male |
| Working Pressure | 360 Bar (5221 psi) |
| Overall Size | 65mm (L) x 38mm (W) |
| Equivalent Length | 0.48 m |

2.15 DISCHARGE NOZZLES

Nozzles are devices through which the agent is discharged within the protected enclosure. Nozzles are available in 180° or 360° and available in size $\frac{3}{8}$ inch, $\frac{1}{2}$ inch, $\frac{3}{4}$ inch, 1 inch, 1 $\frac{1}{4}$ inch, 1 $\frac{1}{2}$ inch and 2 inch. Orifices size determine by design software calculation.




Figure 2.15.1 180° and 360° Discharge Nozzle

Table 2.15.1 Discharge Nozzle Technical Information

| Description | Specification |
|-------------------------|-------------------------|
| Material | Brass (Nickel Plate) |
| Insert | Brass |
| Connection | BSP Female / NPT Female |
| Working Pressure | 90 Bar (1305 psi) |

Table 2.15.2 Discharge Nozzle Technical Information

| Nozzle Size | Part Number | Nozzle Type | Port | Port Size | Height | Wrench Size | Orifice Size Range |
|---------------------------|-------------|-------------|------|-----------|--------|-------------|--------------------|
| 10 mm (3/8 inch) | LF-180IG-10 | 180 | 5 | 4.5 mm | 29 mm | 24 mm | 4.9 mm – 9.6 mm |
| 15 mm (1/2 inch) | LF-180IG-15 | 180° | 5 | 6.7 mm | 36 mm | 30 mm | 6.2 mm – 12.2 mm |
| 20 mm (3/4 inch) | LF-180IG-20 | 180° | 9 | 6.7 mm | 46 mm | 38 mm | 8.2 mm – 16.2 mm |
| 25 mm (1 inch) | LF-180IG-25 | 180° | 9 | 8.4 mm | 55 mm | 45 mm | 10.4 mm – 20.6 mm |
| 32 mm (1 1/4 inch) | LF-180IG-32 | 180° | 9 | 10.7 mm | 64 mm | 50 mm | 14.0 mm – 27.0 mm |
| 40 mm (1 1/2 inch) | LF-180IG-40 | 180° | 14 | 10.7 mm | 77 mm | 60 mm | 16.0 mm – 31.5 mm |
| 50 mm (2 inch) | LF-180IG-50 | 180° | 14 | 13.4 mm | 94 mm | 80 mm | 20.5 mm – 40.5 mm |
| 10 mm (3/8 inch) | LF-360IG-10 | 360° | 8 | 3.6 mm | 29 mm | 24 mm | 4.9 mm – 9.6 mm |
| 15 mm (1/2 inch) | LF-360IG-15 | 360° | 8 | 5.4 mm | 36 mm | 30 mm | 6.2 mm – 12.2 mm |
| 20 mm (3/4 inch) | LF-360IG-20 | 360° | 16 | 5.0 mm | 46 mm | 38 mm | 8.2 mm – 16.2 mm |
| 25 mm (1 inch) | LF-360IG-25 | 360° | 16 | 6.3 mm | 55 mm | 45 mm | 10.4 mm – 20.6 mm |
| 32 mm (1 1/4 inch) | LF-360IG-32 | 360° | 16 | 8.0 mm | 64 mm | 50 mm | 14.0 mm – 27.0 mm |
| 40 mm (1 1/2 inch) | LF-360IG-40 | 360° | 24 | 8.2 mm | 77 mm | 60 mm | 16.0 mm – 31.5 mm |
| 50 mm (2 inch) | LF-360IG-50 | 360° | 24 | 10.2 mm | 94 mm | 80 mm | 20.5 mm – 40.5 mm |

2.16 SELECTOR VALVE

Selector valves are flow control valves with open and closed condition. Selector valve used in application where multiple enclosure or areas require to be protected from a single bank cylinder system. All selector valves are equipped with pneumatic actuators and limit switches.




Figure 2.16.1 Selector Valve

Table 2.16.1 Selector Valve Technical Information

| Description | Specification |
|---------------------------------|------------------------|
| Material | Stainless Steel |
| Connection | BSP |
| Working Pressure | 140 Bar (2030 psi) |
| Nominal Control Pressure | 6 Bar |
| Control Pressure zone | 6 – 10 Bar |
| Complete Switching Time | ≤ 3 s |
| Opening Angle | 90°C |
| Voltage | 12 – 250 V AC/DC |
| Operating Current | 0.1 – 10 A |
| Limit switch | 2 change over contacts |

Table 2.16.2 Selector Valve (threaded) Technical Information

| Size | Part Number | Thread Connection | Weight |
|--------------|--------------|----------------------|---------|
| DN 20 | LF-DIV20-BSP | $\frac{3}{4}$ " BSP | 6.2 kg |
| | LF-DIV20-NPT | $\frac{3}{4}$ " NPT | |
| DN 25 | LF-DIV25-BSP | 1" BSP | 7.0 kg |
| | LF-DIV25-NPT | 1" NPT | |
| DN 32 | LF-DIV32-BSP | $1\frac{1}{4}$ " BSP | 11.0 kg |
| | LF-DIV32-NPT | $1\frac{1}{4}$ " NPT | |
| DN 40 | LF-DIV40-BSP | $1\frac{1}{2}$ " BSP | 15.8 kg |
| | LF-DIV40-NPT | $1\frac{1}{2}$ " NPT | |
| DN 50 | LF-DIV50-BSP | 2" BSP | 18.5 kg |
| | LF-DIV50-NPT | 2" NPT | |

Table 2.16.3 Selector Valve (ISO Flange) Technical Information

| Size | Part Number | Connection | Weight |
|---------------|---------------|------------|----------|
| DN 63 | LF-DIV65-ISO | 2-1/2" | 48.4 kg |
| DN 80 | LF-DIV80-ISO | 3" | 80.1 kg |
| DN 100 | LF-DIV100-ISO | 4" | 113.4 kg |

Table 2.16.4 Selector Valve (DIN Flange) Technical Information

| Size | Part Number | Connection | Weight |
|---------------|---------------|------------|---------|
| DN 63 | LF-DIV65-DIN | 2-1/2" | 59.5 kg |
| DN 80 | LF-DIV80-DIN | 3" | 81.5 kg |
| DN 100 | LF-DIV100-DIN | 4" | 105 kg |

2.17 PILOT HOSE FITTING ADAPTOR

Connection adaptor and fitting for pilot line.




Figure 2.17.1 Connection adaptor and fitting

Table 2.17.1 Connection adaptor and fitting Technical Information

| Description | Specification | | | |
|-------------------------|----------------------|----------------------|-----------|---------------------|
| Part Number | LF-PHA | LF-SORS | LF-PVE | LF-SORT |
| Type | Straight | Tee (swivel on side) | Elbow | Tee (swivel on run) |
| Material | Steel (Zinc plated) | | | |
| Connection | 1/8" BSP x M12 x 1.5 | M12 x 1.5 | M12 x 1.5 | M12 x 1.5 |
| Working Pressure | 360 Bar (5221 psi) | | | |

2.18 PILOT VALVE ADAPTOR

Connection adaptor for pilot cylinder to pilot line.




Figure 2.18.1 Pilot Valve Adaptor

Table 2.18.1 Pilot Valve Adaptor Technical Information

| Description | Specification |
|-------------------------|--------------------|
| Part Number | LF-PVA |
| Material | Brass |
| Connection (Pilot Hose) | M12 x 1.5 |
| Connection (Valve) | M21.8 x 1/14" |
| Working Pressure | 360 Bar (5221 psi) |

2.19 PILOT LINE CHECK VALVE

The pilot line check valve is used to maintain pressure in a particular section of the pilot line or to ensure that nitrogen pressure from the pilot cylinder is operating the correct bank of cylinders.

A system using selector valve which consist of different numbers of cylinders for each hazard enclosure, can use the pilot line check valve to ensure the pilot pressure opens only the correct cylinder from the bank.




Figure 2.19.1 Pilot Line Check Valve

Table 2.19.1 Pilot Line Check Valve Technical Information

| Description | Specification |
|-------------------------|--------------------|
| Part Number | LF-CVPL |
| Material | Stainless steel |
| Connection | 1/8" BSP Female |
| Working Pressure | 360 Bar (5221 psi) |

2.20 CYLINDER LABEL

The cylinder label consists of cylinder part number, cylinder serial number, filling date, tare weight, charge weight, gross weight, fill density and fill location.




Figure 2.20.1 Cylinder Label

2.21 MANIFOLDS

Manifold is a steel pipework where contents of multiple cylinders discharged and direct connected to the appropriate pipe distribution system.




Figure 2.21.1 Manifold – Single Row

Table 2.21.1 Manifold Single Row Technical Information

| Description | Specification | |
|-------------------------|--|-------|
| Cylinder size | 80 L | 140 L |
| Class | Schedule 80 | |
| Paint | Epoxy Powder Coating (Black) | |
| Working Pressure | 90 bar | |
| Test Pressure | 180 bar | |
| Port* | 2-8 | |
| Size | 3/4", 1", 1-1/4", 1-1/2", 2", 2-1/2", 3", 4" | |

*Additional ports upon request.

Table 2.21.3 80L Manifold Single Row Part Number

| MANIFOLD SIZE | 20mm | 25mm | 32mm | 40mm | 50mm | 65mm | 80mm | 100mm |
|-----------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|
| No. of Port = 2 | LF-2COM20-80 | LF-2COM25-80 | LF-2COM32-80 | LF-2COM40-80 | LF-2COM50-80 | | | |
| No. of Port = 3 | LF-3COM20-80 | LF-3COM25-80 | LF-3COM32-80 | LF-3COM40-80 | LF-3COM50-80 | LF-3COM65-80 | LF-3COM80-80 | |
| No. of Port = 4 | | LF-4COM25-80 | LF-4COM32-80 | LF-4COM40-80 | LF-4COM50-80 | LF-4COM65-80 | LF-4COM80-80 | |
| No. of Port = 5 | | LF-5COM25-80 | LF-5COM32-80 | LF-5COM40-80 | LF-5COM50-80 | LF-5COM65-80 | LF-5COM80-80 | LF-5COM100-80 |
| No. of Port = 6 | | | LF-6COM32-80 | LF-6COM40-80 | LF-6COM50-80 | LF-6COM65-80 | LF-6COM80-80 | LF-6COM100-80 |
| No. of Port = 7 | | | LF-7COM32-80 | LF-7COM40-80 | LF-7COM50-80 | LF-7COM65-80 | LF-7COM80-80 | LF-7COM100-80 |
| No. of Port = 8 | | | | LF-8COM40-80 | LF-8COM50-80 | LF-8COM65-80 | LF-8COM80-80 | LF-8COM100-80 |

Table 2.21.4 140L Manifold Single Row Part Number

| MANIFOLD SIZE | 25mm | 32mm | 40mm | 50mm | 65mm | 80mm | 100mm |
|-----------------|---------------|---------------|---------------|---------------|---------------|----------------|----------------|
| No. of Port = 2 | LF-2COM25-140 | LF-2COM32-140 | LF-2COM40-140 | LF-2COM50-140 | | | |
| No. of Port = 3 | LF-3COM25-140 | LF-3COM32-140 | LF-3COM40-140 | LF-3COM50-140 | LF-3COM65-140 | LF-3COM80-140 | |
| No. of Port = 4 | | LF-4COM32-140 | LF-4COM40-140 | LF-4COM50-140 | LF-4COM65-140 | LF-43COM80-140 | |
| No. of Port = 5 | | LF-5COM32-140 | LF-5COM40-140 | LF-5COM50-140 | LF-5COM65-140 | LF-5COM80-140 | |
| No. of Port = 6 | | | LF-6COM40-140 | LF-6COM50-140 | LF-6COM65-140 | LF-6COM80-140 | |
| No. of Port = 7 | | | | LF-7COM50-140 | LF-7COM65-140 | LF-7COM80-140 | LF-7COM100-140 |
| No. of Port = 8 | | | | LF-8COM50-140 | LF-8COM65-140 | LF-8COM80-140 | LF-8COM100-140 |




Figure 2.21.2 Manifold – Double Row

Table 2.21.2 Manifold Double Row Technical Information

| Description | Specification | |
|-------------------------|------------------------------|------------------|
| Cylinder size | 80 L | 140 L |
| Class | Schedule 80 | |
| Paint | Epoxy Powder Coating (Black) | |
| Working Pressure | 90 bar | |
| Test Pressure | 180 bar | |
| Port* | 6 | |
| Size | Part Number | |
| 2" | LF-DR6COM50-80 | LF-DR6COM50-140 |
| 2-1/2" | LF-DR6COM65-80 | LF-DR6COM65-140 |
| 3" | LF-DR6COM80-80 | LF-DR6COM80-140 |
| 4" | LF-DR6COM100-80 | LF-DR6COM100-140 |

*Additional ports upon request.

2.22 DISCHARGE PRESSURE SWITCH

The discharge pressure switch function by sending signal to a control panel during a system discharged. It activates by the agent pressure during discharged and can be reset manually by pushing the top stem after activation.

Table 2.22.1 Discharge Pressure Switch Technical Information

| Description | Specification |
|-----------------------------------|--|
| Part Number | LF-DPS |
| Body Material | Brass |
| Cover Plate | Mild Steel |
| Connection | 1/2" NPT |
| Switch Configuration | 3PDT, Three Pole Double Throw |
| Minimum Actuation Pressure | 4 bar (58psi) |
| Maximum Operating Pressure | 60 bar (870psi) |
| Electrical Rating | 10A 250VAC 15A 125VAC 3/4HP, 250VAC 1,2, or 3 phase |
| Overall Size | 100 mm (L) x 92mm (W) x 123mm(H) 3.94 inch(L) x 3.62 inch(W) x 4.84 inch(H) |




Figure 2.23.1 Discharge Pressure Switch & Wiring Diagram

3.0 SYSTEM DESIGN

The design section provides information to understand the characteristics of LIFECO-01 especially its flow from storage cylinder to the piping network and discharge via nozzle. The systems shall be designed, installed and maintained in accordance with NFPA 2001 and all regulations mentioned in this manual.

3.1 ENCLOSURE DATA

The following are steps to follow to design a LIFECO-01 Engineered Total Flooding Fire Suppression system:

- 3.1 It is important for system designer to conduct a hazard evaluation and survey of the enclosure that needs automatic suppression system protection to obtain specific information appertaining to the enclosure. In the absence of a site survey, the accurate information must be obtained from the drawing and customer confirmation prior to install.
- 3.2 Typical data and information such as enclosure volume, raised floor volume, above ceiling volume, Air conditioning and ventilation system configuration, smoke ventilator system and other related characteristic of the enclosure can be crucial to assist the LIFECO-01 system designer to calculate and design to appropriate requirement.
- 3.3 Based on the hazard class fire (Class A, B & C), the design concentration by volume will be assigned. (Refer to Table 3.2.1)
- 3.4 The minimum and maximum ambient temperatures within the protected space. (Hazard enclosure temperature will affect the agent quantity required. The higher the enclosure temperature, the less Inert gas agent is required. Conversely, the lower the enclosure temperature, the more Inert gas agent is required.)
- 3.5 Calculating Inert gas agent quantity shall require the net protected volume of the enclosure multiply by the design concentration at minimum ambient temperature.
- 3.6 The extinguishing requirements per volume of protected space are shown in Table 3.2.2 for various level of concentration.
- 3.7 Determination of the ventilation system requirement. (Refer to Section 3.4)

When the system is discharged into a complete enclosure, normal gaps under doorways shall not affect system working performance. If there are openings in the protected volume, they must be sealed. Doors, air conditioner duct vents and dampers should be shut down prior to the time of discharge. Sufficient time must be allowed for the dampers to close before system discharge.

3.2 LIFECO-01 DESIGN CONCENTRATIONS

Table 3.2.1 – LIFECO-01 Fire Suppression Minimum Design Concentration Tested to UL2127 & FM5600

| Hazard | Minimum design concentration, % v/v |
|-----------------------------------|--|
| | IG-01 |
| Class A | 40.70% |
| Class B (Commercial heptane fuel) | 56.43% |
| Class C | 45.78% |

The minimum requirements for total flooding clean agent fire extinguishing systems are determined according to NFPA 2001 Standard on Clean Agent Fire Extinguishing Systems. Minimum design concentration shown in Table 3.2.1 is the minimum extinguishing concentration (MEC) plus a safety factor.

Class A hazards: safety factors of 1.2

Class B hazards: safety factors of 1.3

Class C hazards: safety factors of 1.35

Table 3.2.2 – IG-01 Total Flooding Quantity (SI Units)

| Temp (t) (°C) ^c | Specific Vapor Volume (s) (m ³ /kg) ^d | Volume Requirements of Agent per Unit Volume of Hazard ($V_{\text{agent}}/V_{\text{enclosure}}^b$) | | | | | | | |
|-------------------------------|--|--|--------|--------|--------|--------|--------|--------|--------|
| | | Design Concentration (% by Volume) ^e | | | | | | | |
| 34 | 37 | 40 | 42 | 47 | 49 | 58 | 62 | | |
| -20 | 0.5201 | 0.4812 | 0.5350 | 0.5915 | 0.6308 | 0.7352 | 0.7797 | 1.0046 | 1.1205 |
| -10 | 0.5406 | 0.4629 | 0.5147 | 0.5691 | 0.6068 | 0.7073 | 0.7501 | 0.9664 | 1.0779 |
| 0 | 0.5612 | 0.4459 | 0.4950 | 0.5482 | 0.5846 | 0.6814 | 0.7226 | 0.9310 | 1.0384 |
| 10 | 0.5817 | 0.4302 | 0.4784 | 0.5289 | 0.5640 | 0.6573 | 0.6971 | 0.8981 | 1.0018 |
| 15 | 0.5920 | 0.4227 | 0.4701 | 0.5197 | 0.5542 | 0.6459 | 0.6850 | 0.8828 | 0.9844 |
| 20 | 0.6023 | 0.4155 | 0.4620 | 0.5108 | 0.5447 | 0.6349 | 0.6733 | 0.8675 | 0.9676 |
| 30 | 0.6228 | 0.4018 | 0.4468 | 0.4940 | 0.5268 | 0.6139 | 0.6511 | 0.8389 | 0.9357 |
| 35 | 0.6331 | 0.3953 | 0.4395 | 0.4860 | 0.5182 | 0.6040 | 0.6406 | 0.8253 | 0.9205 |
| 40 | 0.6434 | 0.3890 | 0.4325 | 0.4762 | 0.5099 | 0.5943 | 0.6303 | 0.8121 | 0.9058 |
| 50 | 0.6639 | 0.3769 | 0.4191 | 0.4634 | 0.4942 | 0.5759 | 0.6108 | 0.7870 | 0.8778 |
| 60 | 0.6845 | 0.3656 | 0.4066 | 0.4495 | 0.4793 | 0.5587 | 0.5925 | 0.7633 | 0.8514 |
| 70 | 0.7050 | 0.3550 | 0.3947 | 0.4304 | 0.4654 | 0.5424 | 0.5752 | 0.7411 | 0.8200 |
| 80 | 0.7256 | 0.3449 | 0.3885 | 0.4240 | 0.4522 | 0.5270 | 0.5589 | 0.7201 | 0.8032 |
| 90 | 0.7461 | 0.3354 | 0.3730 | 0.4124 | 0.4397 | 0.5125 | 0.5436 | 0.7003 | 0.7811 |
| 100 | 0.7666 | 0.3264 | 0.3630 | 0.4013 | 0.4270 | 0.4988 | 0.5290 | 0.6815 | 0.7601 |
| 110 | 0.7872 | 0.3179 | 0.3535 | 0.3908 | 0.4168 | 0.4857 | 0.5152 | 0.6637 | 0.7403 |
| 120 | 0.8077 | 0.3098 | 0.3445 | 0.3809 | 0.4062 | 0.4734 | 0.5021 | 0.6468 | 0.7215 |

This information was taken from **NFPA 2001: 2018 Edition under Annex A**, Table A.5.5.2 (b) IG-01 Total Flooding Quantity (SI Units).

X [agent volume requirements (m³/m³)] = volume of agent required per cubic meter of protected volume to produce indicated concentration at temperature specified.

$$X = 2.303 \times \left(\frac{s_0}{s} \right) \times \log_{10} \left(\frac{100}{100 - C} \right) = \left(\frac{s_0}{s} \right) \times \ln \left(\frac{100}{100 - C} \right)$$

Where:

s_0 [specific volume (m³/kg)] = specific volume of inert gas agent at 21 °C and 1.013 bar absolute

t [temperature (°C)] = design temperature in the hazard area

C [Concentration (%)] = volumetric concentration of inert gas agent in air at the temperature indicated.

IG-01

S [specific volume (m³/kg)] = specific volume of IG-01 can be approximated by $s = 0.5685 + 0.00208t$

The quantity of inert gas agent designed shall be corrected to compensate for ambient pressure that vary more than 11 percent (equivalent to approximately 3000ft (915m) of elevation change) from standard sea level pressure. The corrected agent quantity is calculated by multiplying the calculated weight, W by the elevation correction factor. (See Table 3.2.3)

Table 3.2.3 Atmospheric Correction Factor

| Altitude | Enclosure Pressure | Atmospheric Correction Factor |
|-------------------|---------------------|-------------------------------|
| -3000ft (-0.92km) | 16.25psi (840mm Hg) | 1.11 |
| -2000ft (-0.61km) | 15.71psi (812mm Hg) | 1.07 |
| -1000ft (-0.30km) | 15.23psi (787mm Hg) | 1.04 |
| 0ft (0.00km) | 14.70psi (760mm Hg) | 1.00 |
| 1,000ft (0.30km) | 14.18psi (733mm Hg) | 0.96 |
| 2,000ft (0.61km) | 13.64psi (705mm Hg) | 0.93 |
| 3,000ft (0.91km) | 13.12psi (678mm Hg) | 0.89 |
| 4,000ft (1.22km) | 12.58psi (650mm Hg) | 0.86 |
| 5,000ft (1.52km) | 12.04psi (622mm Hg) | 0.82 |
| 6,000ft (1.83km) | 11.53psi (596mm Hg) | 0.78 |
| 7,000ft (2.13km) | 11.03psi (570mm Hg) | 0.75 |
| 8,000ft (2.45km) | 10.64psi (550mm Hg) | 0.72 |
| 9,000ft (2.74km) | 10.22psi (528mm Hg) | 0.69 |
| 10,000ft (3.05km) | 9.77psi (505mm Hg) | 0.66 |

3.3 INERT GAS AGENT CALCULATION EQUATION

The quantity of agent required for hazard protection can be calculated from the equation below:

$$X = 2.303 \times \left(\frac{S_0}{S} \right) \times \log_{10} \left(\frac{100}{100 - C} \right) = \left(\frac{S_0}{S} \right) \times \ln \left(\frac{100}{100 - C} \right) \times EC$$

Where:

X [agent volume requirements (m³/m³)] = volume of agent required per cubic meter of protected volume to produce indicated concentration at temperature specified.

S₀ [specific volume (m³/kg)] = specific volume of inert gas agent at 21 °C and 1.013 bar absolute

t [temperature (°C)] = design temperature in the hazard area

C [Concentration (%)] = volumetric concentration of inert gas agent in air at the temperature indicated.

EC = Elevation Correction

IG-01

S [specific volume (m³/kg)] = specific volume of IG-01 can be approximated by s = 0.5685 + 0.00208t

3.4 VENTING REQUIREMENTS

Protected enclosure by an inert gas clean agent fire suppression system may require a pressure vent which is designed to allow pressure relief within the enclosure during the system discharge. Venting is important to prevent over or under pressurization to the hazard enclosure which also prevent consequences such as structural damage which can lead to loss of extinguishant.

Other than venting, integrity of the enclosure is also a requirement to determine by conducting room integrity test to ensure the agent is able to retain in the enclosure no less than retention time of 10 minutes. Longer retention time means holding of the agent in the enclosure is longer which is favorable to extinguish deep seated hazard. Due to the discharge of the fire suppression agent into the enclosure will give rise in pressure within the enclosure which can affect the structural integrity of the enclosure.

Venting area can be calculated in the hydraulic flow calculation software provided. For the calculation, information requires the maximum strength of the weakest wall, floor or ceiling of the enclosure.

Note: It is client's responsibility to provide all the information required for venting calculation.

3.5 ENGINEERED SYSTEMS

Inert LIFECO System uses of LIFECO-UK Clean Agent Flow Calculation Software v4.10 for predicting the flow of agent through a pipe network from storage cylinder to the discharge nozzle developed by Jensen Hughes, Inc.

The calculation software requires the designer to input the information of the protected enclosure to calculate the required pipe sizes, nozzle sizes, nozzle drill sizes, average nozzle pressure and discharge time as well. Due to the system design calculation is important and critical to the success of the suppression system, hence, only trained designers are allowed to perform system calculations and these are conducted in house or by authorized suppliers. The system design shall be within the listed limitations.

Note: The calculation method has been investigated for specific types of fittings, types of pipe and pipe inside diameter. When the specified limitations are not maintained there is the risk that the system will not supply the required quantity of extinguishing agent.

3.6 PIPE & FLOW LIMITATIONS

The Hydraulic Flow Calculation Software will select the pipe sizes for each section in the piping network based on the Inert Gas flowrate for each section. However, the pipe sizes also can be input manually into the program if desired. The selected pipe sizes must fall within the minimum and maximum range of flowrate as shown in general guideline in Table 3.6.1.

Table 3.6.1 Minimum and Maximum Flow Rate Guidelines

| Nominal Pipe Size mm (in) | Flow Rate Range | | Type of Pipe |
|------------------------------|--------------------|------------------|--------------|
| | CFM | CMM | |
| 6 (1/4) | 47.41 – 266.07 | 1.34 – 7.54 | Schedule 40 |
| 10 (3/8) | 86.97 – 488.08 | 2.46 – 13.81 | Schedule 40 |
| 15 (1/2) | 138.43 – 776.92 | 3.92 – 22 | Schedule 40 |
| 20 (3/4) | 250.38 – 1403.4 | 7.09 – 39.74 | Schedule 40 |
| 25 (1) | 415.65 – 2331.12 | 11.77 – 66.01 | Schedule 40 |
| 32 (1 -1/4) | 740.2 – 4149.12 | 20.96 – 117.49 | Schedule 40 |
| 40 (1-1/2) | 1023.42 – 5737.22 | 28.98 – 162.46 | Schedule 40 |
| 50 (2) | 1730.42 – 9701.29 | 49 – 274.71 | Schedule 40 |
| 65 (2-1/2) | 2514.05 – 14095.85 | 71.19 – 399.15 | Schedule 40 |
| 80 (3) | 3969.37 – 22254.24 | 112.4 – 630.17 | Schedule 40 |
| 100 (4) | 7027.97 – 39402.34 | 199.01 – 1115.75 | Schedule 40 |
| 125 (5) | 11304.22 – 63369.7 | 320.1 – 1794.43 | Schedule 40 |
| 150 (6) | 16632.5 – 93248.38 | 470.98 – 2640.5 | Schedule 40 |
| 6 (1/4) | 42.35 – 237.69 | 1.2 – 6.73 | Schedule 80 |
| 10 (3/8) | 83.09 – 466.31 | 2.35 – 13.19 | Schedule 80 |
| 15 (1/2) | 138.43 – 776.92 | 3.92 – 22 | Schedule 80 |
| 20 (3/4) | 250.38 – 1403.4 | 7.09 – 39.74 | Schedule 80 |
| 25 (1) | 415.65 – 2331.12 | 11.77 – 66.01 | Schedule 80 |
| 32 (1 -1/4) | 740.2 – 4149.12 | 20.96 – 117.49 | Schedule 80 |
| 40 (1-1/2) | 1023.42 – 5737.22 | 28.98 – 162.46 | Schedule 80 |
| 50 (2) | 1730.42 – 9701.29 | 49 – 274.71 | Schedule 80 |
| 65 (2-1/2) | 2514.05 – 14095.85 | 71.19 – 399.15 | Schedule 80 |
| 80 (3) | 3969.37 – 22254.24 | 112.4 – 630.17 | Schedule 80 |
| 100 (4) | 7027.97 – 39402.34 | 199.01 – 1115.75 | Schedule 80 |
| 125 (5) | 11304.22 – 63369.7 | 320.1 – 1794.43 | Schedule 80 |
| 150 (6) | 16632.5 – 93248.38 | 470.98 – 2640.5 | Schedule 80 |

This guideline table is applied for the schedule 40/80 pipe and acts as an approximate only. An actual hydraulic calculation must be performed to confirm both pipe sizes and the feasibility of the piping network.

Table 3.6.2 Hydraulic Flow Calculation Program Limitation

| Description | Program Parameters |
|--|---------------------------|
| Discharge Time Interval | 30 – 120 seconds |
| Maximum Pipe Volume to Cylinder Volume Ratio | 104 % |
| Minimum Pipe Volume Ratio Before First Tee | 5 % |
| Minimum Nozzle Orifice Area to Pipe Ratio | 15% |
| Maximum Nozzle Orifice Area to Pipe Ratio | 60% |
| Minimum Average Nozzle Pressure | 10.1 Bar (146.49 psi) |
| Maximum Arrival Time Imbalance | 1.0 second |
| Critical Pipe Length | 17 diameters |
| Bull Tee Split | 10:90 (Min); 50:50 (Max) |
| Side Tee Split | 10:90 (Min); 50:50 (Max) |

When the above conditions are not met, the computer screen displays a warning. It is then up to the designer to correct them.

3.7 TEE LIMITATIONS

To maintain the turbulent flow in piping and predictable flow characteristics at tee splits, certain guidelines relating to tee orientation must be taken into consideration. The exit branches of the tees must be in the horizontal plane. There are two types of tee used for this system, bull tee and side tee.




Figure 3.7.1 Minimum Bull Tee Imbalance



Figure 3.7.2 Maximum Bull Tee Imbalance




Figure 3.7.3 Minimum Side Tee Imbalance



Figure 3.7.4 Maximum Side Tee Imbalance




Figure 3.7.5 Correct Bull Tee Splits Orientation




Figure 3.7.6 Correct Side Tee Splits Orientation




Figure 3.7.7 Incorrect Side Tee Splits Orientation

Table 3.7.1 Equivalent Length for Pipe Fittings

| Nominal Size mm (in) | 90° Elbow | | 45° Elbow | | Through Tee | | Side Tee | | Union | |
|----------------------|-----------|------|-----------|------|-------------|------|----------|------|-------|------|
| | ft | m | ft | m | ft | m | ft | m | ft | m |
| 6 (1/4) | 1.3 | 0.4 | 0.6 | 0.18 | 0.8 | 0.24 | 2.7 | 0.82 | 0.3 | 0.09 |
| 10 (3/8) | 1.3 | 0.4 | 0.6 | 0.18 | 0.8 | 0.24 | 2.7 | 0.82 | 0.3 | 0.09 |
| 15 (1/2) | 1.7 | 0.52 | 0.8 | 0.24 | 1.0 | 0.3 | 3.4 | 1.04 | 0.4 | 0.12 |
| 20 (3/4) | 2.2 | 0.67 | 1.0 | 0.3 | 1.4 | 0.42 | 4.5 | 1.37 | 0.5 | 0.15 |
| 25 (1) | 2.8 | 0.85 | 1.3 | 0.4 | 1.8 | 0.55 | 5.7 | 1.74 | 0.6 | 0.18 |
| 32 (1-1/4) | 3.7 | 1.13 | 1.7 | 0.52 | 2.3 | 0.7 | 7.5 | 2.29 | 0.8 | 0.24 |
| 40 (1-1/2) | 4.3 | 1.31 | 2.0 | 0.61 | 2.7 | 0.82 | 8.7 | 2.65 | 0.9 | 0.27 |
| 50 (2) | 5.5 | 1.68 | 2.6 | 0.79 | 3.5 | 1.06 | 11.2 | 3.41 | 1.2 | 0.37 |
| 65 (2-1/2) | 6.6 | 2.01 | 3.1 | 0.94 | 4.1 | 1.25 | 13.4 | 4.08 | 1.4 | 0.43 |
| 80 (3) | 8.2 | 2.5 | 3.8 | 1.16 | 5.1 | 1.55 | 16.6 | 5.06 | 1.8 | 0.55 |
| 100 (4) | 10.7 | 3.26 | 5.0 | 1.52 | 6.7 | 2.01 | 21.8 | 6.64 | 2.4 | 0.73 |
| 125 (5) | 13.4 | 4.08 | 6.3 | 1.92 | 8.4 | 2.56 | 27.4 | 8.35 | 3.0 | 0.91 |
| 150 (6) | 16.2 | 4.94 | 7.6 | 2.32 | 10.1 | 3.08 | 32.8 | 10.0 | 3.5 | 1.07 |

3.8 DISCHARGE TIME

The discharge time required to achieve 95% of the minimum design concentration for flame extinguishment shall not exceed 60 seconds for Class B fuel hazards, 120 seconds for Class A surface-fire hazards or Class C hazards specified in NFPA 2001.

3.9 AGENT STORAGE CYLINDER

Inert gas agent shall be stored in approved cylinders to retain specific amount of compressed gas at ambient temperature. The cylinders shall be filled as according to Table 5.0 and pressurized to 200 Bar or 300 Bar @ 15°C (2900 psi or 4351 psi @ 59°F). The filled cylinders shall be allowed to be located within or outside the protected hazard enclosure. However, they shall not be placed where they can be rendered inoperable due to exposure to direct sunlight, chemicals, mechanicals and bad weather condition (temperature other than the operating temperature range of -20°C to 55°C (-4°F to 131°F). The hydraulic flow calculations assume an agent temperature of 15°C (59°F). **When the storage temperature varies by $\pm 5.5^{\circ}\text{C}$ (42°F) from the normal ambient temperature, there is the risk that the system will not supply the designated quantity of extinguishing agent.**

3.10 MANIFOLDS / PIPING

For Inert gas in a multiple cylinder system, all cylinders are connected to the same manifold or pipe must be the same size and filled with same agent weight and pressure (200 bar or 300 bar) system. System can be connected with reserves. Reserves cylinders are duplication of the same bank of agent cylinders from the main and connected into a common manifold.

3.11 DISCHARGE NOZZLE

There are two type of discharge nozzle configurations namely:

- The 180° discharge nozzle which provides a 180° discharge pattern and designed to be mounted adjacent to a wall of the hazard.
- The 360° discharge nozzle which provides a 360° discharge pattern and designed to be installed in the center of the hazard.

There are certain factors such as coverage area and height limitation must be observed with each nozzle configuration to ensure proper agent distribution during discharged.

| | | |
|---------------------------------------|----------------------|--------------------------------|
| Nozzle Maximum Coverage Area | 108.16m ² | |
| *Maximum Protection Height | 6.33m | |
| Minimum Void Height | 300mm | |
| Maximum elevation change | No Limit | |
| Nozzle Position (minimum void height) | 180° | Pendant / Upright |
| | 360° | |
| Maximum Nozzle Spacing | 180° | 300mm from Wall |
| | 360° | Centerline, 300mm from Ceiling |

*If the hazard's height exceeds 6.33m, multiple tiers of nozzles must be used for each 6.33m increment of the enclosure height.




Table 3.11.1 Discharge Nozzle Discharge Radius

| Nozzle Configuration | Radius |
|----------------------|---------|
| 180° | 11.62 m |
| 360° | 7.35 m |

3.12 AGENT CALCULATION SAMPLE




Figure 3.12.1 Server Rooms size

For example, A server room with dimension 4.98m (L) x 4.98m (W) x 3.50 m (H) is protected with an IG-01 system. The room is classified as Class C hazards. At minimum ambient temperature, 15°C (59°F).

Example:

To calculate the volume of Switch Room,

Server Room Volume, $V = 4.98 \text{ m} \times 4.98 \text{ m} \times 3.5 \text{ m}$

$$= 86.8014 \text{ m}^3$$

To calculate the specific volume at 15 °C,

S [specific volume (m³/kg)] = 0.5685 + 0.00208t

$$= 0.5685 + 0.00208(15)$$

$$= 0.5997$$

To calculate the specific volume at 21 °C,

S_0 [specific volume (m³/kg)] = 0.5685 + 0.00208t

$$= 0.5685 + 0.00208(21)$$

$$= 0.61218$$

To calculate the agent required per protected volume,

IG-01 Class C Design Concentration = 45.78%

$$X = 2.303 \times \left(\frac{S_0}{S} \right) \times \log_{10} \left(\frac{100}{100 - C} \right) = \left(\frac{S_0}{S} \right) \times \ln \left(\frac{100}{100 - C} \right)$$

$$X = 0.62486 \text{ m}^3/\text{m}^3$$

To calculate the agent required,

$$V = 86.8014 \text{ m}^3$$

$$\text{Agent required} = X \times V$$

$$= 0.62486 \text{ m}^3/\text{m}^3 \times 86.8014 = 54.24 \text{ m}^3$$

To calculate Number of cylinders required,

Agent capacity per 140L 200bar cylinder = 29.87m³

Total number of cylinders = $54.24 \text{ m}^3 / 29.87 \text{ m}^3 = 1.82 \approx 2$ nos of 140L 200bar cylinders.




Figure 3.12.2 System Design Flow Chart

4.0 SYSTEMS MECHANICAL INSTALLATION

- General Information

All mechanical installation work carried out shall be performed by a trained total flooding system installation contractor with the correct equipment and the relevant experience in gaseous extinguishing systems. Prior to installation commence, installing contractor shall refer to system installation drawing prepared for the specific hazard or appropriately endorsed working drawing and be satisfied with the system designed complies to requirement. Installation drawing shall contain information as follow:

- i. Detailed hazard's layout drawing
- ii. Net volume of enclosure
- iii. Quantity of Agent designed
- iv. Cylinder location with indication of master unit / slave units
- v. Detection system layout
- vi. Suppression control panel's line drawing
- For all installations the detection, manual pull stations, and fire suppression control panel shall be accepted by the Authority Having Jurisdiction.
- The cylinder location is identified on the system drawings and should be protected from bad weather and easy for accessible when service and maintenance. The cylinders must be firmly secured to a wall in a vertical orientation only.
- The back channel of the mounting bracket is fitted to a wall by using suitable bolt.
- The cylinder is position with pressure gauge face outside / valve outlet pointing left.
- The cylinder is then strap and secure with bolt.
- Remove the safety cap from the discharge valve outlet.
- Fit and connect all the cylinder with discharge hose, check valve and constant pressure regulators to the manifold.
- The cylinder is disconnected and refit with safety cap. Once the pipework and nozzle has been installed, then reconnect the pipe to the cylinder.



CAUTION

Do not tight the pipe to the valve outlet excessively. This may cause the valve outlet thread to be damaged and indirectly affected the system operation.




Figure 4.0.1 Bracket Fixing Heights

| Cylinder Size | Height from Floor to Bracket | Label Location from Floor |
|---------------|------------------------------|---------------------------|
| | | A |
| 80L 200bar | 1200 mm (47.25 inch) | 1550 mm (61 inch) |
| 80L 300bar | | 1550 mm (61 inch) |
| 140L 200bar | | 1500 mm (59 inch) |
| 140L 300bar | | 1550 mm (61 inch) |

Bracket Installation:






Figure 4.0.2 Bracket Top View


1. Install Unistrut channel to wall or supporting structure.
2. Install Stud with C channel stopper into Unistrut channel. Tighten stud with spanner.
3. Fit stud into bracket strap nut. Tighten nut with spanner.



4. Repeat step 2 and slot the second strap to the first strap channel. Then tighten nut with spanner.



5. Install additional stud provided to first row strap and connect to second row strap.



4.1 PIPE INSTALLATION

The pipework installs according to the as built installation drawing and followed to:

- The piping material must conform to the requirements of NFPA 2001. Joint compound, tape, or thread lubricant shall be applied only to the male threads of the joint.
- The piping system should comply with the pressure requirements specified in the Table below.

Table 4.1.1 Steel Pipe Requirements

| Pipe Size | Connection | Pipe Class |
|-----------------|------------|----------------|
| ½ inch – 6 inch | Threaded | Schedule 40/80 |

A dirt trap consisting of a tee with a capped nipple, at least 2 inch long, shall be installed at the end of each pipe run. (Source: section 4.2.1.6, NFPA 2001: 2018 Edition)

Each of the pipe section shall be cleaned internally after preparation and before assembly by means of swabbing, utilizing a suitable nonflammable cleaner. The pipe network shall be free of particulate matter and oil residue before installation of nozzles or discharge devices.

4.2 ACTUATION INSTALLATION

4.2.1 Installation of Electrical Actuator

Location of Installation

The electrical actuator is built in with Solenoid discharge valve 200bar (PN: LF-IGEASV200) and 300bar (PN: LF-IGEASV300).



Figure 4.2.1 Solenoid valve with built in electrical actuator



CAUTION

The pilot wire must be free of any voltage when assembling the connector, otherwise accidental discharge of the extinguishing system may occurred.

- Interchanging polarity of the contacts Positive and Negative do not lead to malfunction of the valve. Ensure the ground connection is connected correctly.




Figure 4.2.2 Electrical Actuator Wiring Diagram

4.22 Installation of Manual & Pneumatic Actuator

- Release devices compatibility.

| | Manual Actuator (PN: LF-COMA) | Pneumatic Manual Actuator (PN: LF-COMPA/1) | Pneumatic Manual Actuator (PN: LF-COMPA) | Pneumatic Actuator (PN: LF-COPA) |
|---|----------------------------------|--|--|-------------------------------------|
| Solenoid discharge Valve 200 bar (PN: LF-IGEASV200) | ✓ | ✓ | | |
| Solenoid discharge Valve 300 bar (PN: LF-IGEASV300) | ✓ | ✓ | | |
| Discharge Valve 200bar (PN: LF-IGDV200) | | | ✓ | ✓ |
| Discharge Valve 300bar (PN: LF-IGDV300) | | | ✓ | ✓ |

- Check the thread for impurities and damages.
- Mount and tighten the release devices with a requirement of $15\text{Nm} \pm 1$ (Solenoid valve), $25\text{Nm} \pm 2$ (Discharge valve).
- Do not transport cylinder with release devices mounted. Only installed when system is commissioned.
- Actuated release devices must be reset before mount.




Figure 4.2.3 Solenoid valve with manual, pneumatic manual actuator

Manual actuator (PN: LF-COMA) and Pneumatic Manual actuator (PN: LF-COMPA/1) to be mount to the side of the discharge valve thread M20 x 1.5. Both actuators feature retractable pin which reset when level back to original position.




Figure 4.2.4 Pneumatic Actuator in Non-Fire/Fire Position




Figure 4.2.5 Pilot Hose installation

- Pneumatic actuator (PN: LF-COPA) must be installed on the slave cylinders only. Pin must be reset before mount.
- The pneumatic actuators / pneumatic manual actuators are triggered thru the 1/8" connection thread.
- The pneumatic connection of slave cylinders is achieved by removing the 1/4" pressure plug of the master cylinder valve and fit the male adaptor. Install tee adaptor onto the pneumatic actuators.
- Connect one end of flexible hose to the male adaptor on the master cylinder and another end to the tee adaptor on the pneumatic actuator.




Figure 4.2.6 Cylinder Configuration

- One master cylinder and others slave cylinders are designed for multiple cylinders installed for intended to discharge simultaneously. In case there is a fire occurs, the master cylinder can be activated either electrically or manually. Whereas, the slave cylinders are activated pneumatically from the discharge action of master cylinder.
- Manual actuator (PN: LF-COMA) must be installed onto the master cylinder.
- For system with 2 or more master cylinder in between, pneumatic manual actuator (PN: LF-COMPA or LF-COMPA/1) must be installed on the second master cylinder and so on.

Table 4.2.1 Multiple Cylinders

| Cylinder Size | Master Cylinder (Quantity) | Maximum Slave Cylinder (Quantity) | Maximum Cylinder in total (Quantity) |
|---------------|----------------------------|-----------------------------------|--------------------------------------|
| 80L/140L | 1 | 32 | 33 |

Table 4.2.2 Multiple Cylinders (Pilot Actuation)

| Pilot Cylinder Size | Pilot Cylinder (Quantity) | Maximum Cylinder (Quantity) |
|---------------------|---------------------------|-----------------------------|
| 4L/10L | 1 | 64 |

4.3 INSTALLATION OF SELECTOR VALVE

Location of Installation

The selector valve installed between the end of the manifold and the discharge pipe system of the protected hazard.

Installation Instructions




Figure 4.3.1 Selector Valve Configuration





Figure 4.3.2 Pilot Line Check Valve Connection



- Fit the selector valve to the selector valve manifold.
- Attach the pneumatic tubing from pilot cylinder to the selector valve pressure connection “2”.
- Do not close connection “4”. Connection “4” is for venting purpose.
- The control pressure must be maintained within 6 – 10 bar.
- Connecting thread and flange connection must be free of impurities, grease and adhesive residue.
- Fit the pilot line check valve to the pneumatic actuator with pilot hose adaptor. Using pilot line check valve to control the number of cylinders discharged into designated hazard.
- Various fittings (adaptors, tee and elbow) are available to fit pilot line check valve and pilot hoses.

- h. After a discharge, the pilot line remains pressurized. To ensure the selector valve is in a depressurized state, the pilot hose connected from the pilot cylinder to the selector valve must be disconnected or vented.
- i. The selector valve can be manually reset (closed) using a suitable tool (e.g., a wrench), but only when the system is in a depressurized state. The operation should be performed via the wrench flats on the drive shaft.




Figure 4.3.3 Selector valve resetting

4.4 DETECTION OF CONTROL EQUIPMENT

- The design of a system for automatic detection, signal distribution, alarms, etc. is not always of LIFECO's supply. Therefore, details pertaining to fire detection and alarm operation and maintenance are not included in this manual.
- Control Devices require the use of a UL Listed / FM Approved Fire Alarm Control Panel, that is compatible with the actuation devices and the manual pull stations used to operate LIFECO-01 Engineered Total Flooding Fire Suppression System units. Reference the control panel manual for compatibility information.
- Detection and notification appliances and devices shall be UL Listed / FM Approved and compatible with the control panel. Reference the detectors manual for compatibility information.
- For installations and locations that do not require a UL Listed/FM Approved/NFPA Standard type control panel, detection, and notification, the authority having jurisdiction shall be consulted to determine the appropriate type of control panel, detectors, and notification appliances to be used.

4.5 INSTALLATION OF DISCHARGE PRESSURE SWITCH

Discharge pressure switch can be install on the distribution pipe/ manifold.

- Discharge pressure switch can be installed on the distribution pipe or manifold after constant pressure regulator. It can be install with a $\frac{1}{2}$ " Pipe with Union or it can direct to the manifold with a $\frac{1}{2}$ " nipple.



Figure 4.5.2: Distribution pipe / Manifold- Discharge Pressure Switch Installation

For electrical connection, remove the cover plate and refer to Figure 4.5.3.




Figure 4.5.3: Discharge Pressure Switch Installation Wiring Diagram

IMPORTANT

Clause 8.1.2 Fire Protection Service Technician. Personnel that inspect, service, test, and maintain clean agent fire extinguishing systems shall have knowledge and experience of the maintenance and servicing requirements contained in this standard, of the equipment being serviced or maintained, and of the servicing or maintenance methods and requirements contained in the manufacturer's design, installation, and maintenance manual and any applicable bulletins.

Clause 8.8 Training All personnel who could be expected to inspect, service, test, or maintain fire extinguishing systems shall be trained and kept trained in the functions they are expected to perform.

(Source: NFPA 2001)

5.0 INSPECTION OF SYSTEM AFTER INSTALLATION

A regular program of systematic inspection is established for the continuous proper operation of all LIFECO-01 systems installed. The inspection work shall be conducted by trained and competent personnel. This **system periodically be inspected by trained personnel**. The purpose of periodic inspection is to assure that the system is in full operating condition at all times. Its activity shall identify problems due to wear and tear, and accidental and environmental damages, tampering, changes to hazard characteristic or intended uses or other related changes that could adversely affect the proper performance of the LIFECO-01 system. **This system is made up of units tested within limitations contained in the detailed installation manual. The system designer must be consulted whenever changes are planned for the system or area of protection. An authorized installer or system designer must be consulted after the system has discharged.**

- The openings or sources of agent loss such as cable and duct penetrations into the hazard area should be permanently sealed. Door entering the hazard area should be checked for tightness. Joints where walls contact floors should be sealed as these are potential leak points most often overlooked.
- Inspect hazard layout for any deviation of its initial designed volume. If there are any changes to its initial designed volume, the LIFECO-01 system especially the quantity of the agent must be recalculated and corrected.
- Access passage to the fire suppression system must not be obstructed. A trained and competent personnel must be able to have access to the system within reasonable time determine by fire authorities, insurance authorities and/or by the system user.
- Make sure that the nozzle(s) is(are) cleared of obstruction and free from signs of corrosion or rust. The nozzle(s) must not be painted or tampered by a trained installer or the system user. Use the proper type of nozzle(s) and check that they are correctly installed and properly orientated.
- Inspect all LIFECO-01 cylinders, valves, hoses and other equipment for damages such as cracks, dents, distortions, and worn out or missing parts.
- Cylinders must be checked for pressure drop to determine for any loss of agent due to leakages if any of the above-mention is identified. Check cylinder pressure information label against system's agent requirements.

- Check LIFECO-01 cylinder safety brackets and mounting hardware for damages, broken parts, signs of corrosion and that all cylinder(s) and pipe works are securely fixed and able to hold them in position during system discharge. Ensure no welded pipe works are used for the system installation.
- Check actuator(s) for physical damages, corrosion or dirt. Check electric actuator's connecting wiring for wear and tear or damages. Check wiring voltage is correct for actuation when system is triggered. Check connection faulty if not fully assembled.
- Have a final check that the system is armed and the detecting and actuating systems are operational.
- Perform door fan testing to evaluate enclosure leakage and determine the system ability to maintain the design concentration after system discharge. The software provided for this testing is able to predict the time it will take for a descending interface to fall to a given height. The door fan testing provides a worst-case leakage estimation that is very useful for enclosures with complex hidden leaks, but will generally require more necessary sealing to pass a discharge test. (Refer to NFPA 2001, Appendix C Safety Bulletins)

6.0 MAINTENANCE



WARNING

BEFORE PERFORMING MAINTENANCE PROCEDURES, PLEASE REFER TO THE MATERIAL SAFETY DATA SHEET AND SAFETY BULLETINS IN THE APPENDIX AT THE BACK OF THIS MANUAL.

The user's maintenance program is intended to avoid the consequences of failure of equipment by preserving and/or restoring equipment reliability. This is to assure that the system and equipment is in full operating condition at all times. If inspection indicates areas of rust and corrosion is present, immediately contact your local supplier for the next course of action.

6.1 MONTHLY PREVENTIVE MAINTENANCE PROCEDURES

- 6.1.1 Make a general inspection survey of all cylinders and equipment for damage, leakage or missing parts.
- 6.1.2 Inspect the hazard area against the original layout to ensure that there have been no changes that might affect the proper performance of the LIFECO-01 system. Changes might include partitioning, floor and/or ceiling voids, renovating and openings in an enclosure boundary that the inert gas agent can flow out of.
- 6.1.3 Ensure access to hazard areas, control panel, manual pull stations, nozzle(s), and cylinder(s) are unobstructed and that there are no obstructions to the operation of the equipment or distribution of inert gas agent.
- 6.1.4 Ensure warning signs, safety precautions and operating instructions are posted and clearly visible.
- 6.1.5 Inspect cylinder safety bracket and piping brackets for loose, damaged, or broken parts. Check cylinder brackets and associated parts for corrosion, oil, grease, grime, etc. Tighten loose hardware. Replace damaged parts.

6.2 SEMI-ANNUALLY PREVENTIVE MAINTENANCE PROCEDURES

- 6.2.1 Externally inspect cylinder(s) for signs of damage or unauthorized modifications. Check cylinder labels for damage and that the label descriptions are still visible. Check cylinder brackets and fittings.
- 6.2.2 Inert gas agent must be checked and weighted to ensure quantity tallies with charged weight as indicated on the cylinder label.
- 6.2.3 Inspection procedures:



CAUTION

DISCONNECT ALL ELECTRICAL ACTUATOR(S) TO PREVENT ACCIDENTAL SYSTEM DISCHARGE. **FOR SYSTEM SUPERVISION – DO NOT USE LOOPED WIRE UNDER TERMINALS, BREAK WIRE RUN TO PROVIDE SUPERVISION OF CONNECTIONS.**

- Remove electric actuator's electrical port from the cylinder valve.
- Remove all release device from the cylinder valve.
- Loosen and disconnect the discharge pipe from the cylinder valve's outlet port.
- Install the safety cap onto the cylinder valve's outlet port.
- Loosen and remove the cylinder safety brackets.
- Check the pressure gauge reading on each cylinder. The nominal pressure should be approximately 200 Bar or 300 Bar @ 15°C (2900 psi or 4351 psi @ 59°F). However, the pressure will vary depend on temperature. If pressure loss exceeds 10% of the nominal pressure, check the cylinder for leaks, repair and refill as necessary.
- Inspect discharge pipes for loose fittings, damaged threads, cracks, rust, kinks, and distortion.
- Tighten loose fittings and replace pipe(s) show corrosion or mechanical damage.

6.2.4 Inspect all the hoses installed for physical damages.

6.2.5 Inspect discharge nozzle(s) for dirt, dust, debris, and physical damage. Replace damaged or clogged nozzle(s) and clean out where necessary.

6.2.6 Check the condition of manual / pneumatic and electrical actuators and do replacement where appropriate. Check all valve assemblies for damages and leaks. If leaking occurs, the contents of the cylinder must be transferred to another cylinder before reconditioning the valve.



WARNING

NEVER ATTEMPT TO RECONDITION THE VALVE UNTIL THE CONTENTS OF THE CYLINDER HAVE BEEN TRANSFERRED AND THE PRESSURE GAUGE READS 0 BAR.

6.3 EVERY TWO YEARS PREVENTIVE MAINTENANCE PROCEDURES



WARNING

DO NOT USE OXYGEN OR WATER TO BLOW OUT PIPE LINES. THE USE OF OXYGEN IS ESPECIALLY DANGEROUS AS THE POSSIBLE PRESENCE OF OIL MAY CAUSE AN EXPLOSION.



CAUTION

DISCONNECT ELECTRICAL POINT FROM SOLENOID DISCHARGE VALVE TO PREVENT ACCIDENTAL SYSTEM DISCHARGE. **FOR SYSTEM SUPERVISION – DO NOT USE LOOPED WIRE UNDER TERMINALS, BREAK WIRE RUN TO PROVIDE SUPERVISION OF CONNECTIONS.**

- 6.3.1 Remove electrical actuator from the cylinder valve's actuation port.
- 6.3.2 Remove all cylinder(s) from the safety bracket including disconnecting its valve from the discharge pipes. Install safety cap onto the cylinder valve's outlet port.
- 6.3.3 Remove any nozzle(s) from the pipe network to allow any foreign matter to blow clear.
- 6.3.4 Blow out all distribution piping with dry nitrogen to ensure the pipe work is not blocked or clogged, verifying that dry nitrogen is discharging at the end of the pipe where the nozzle(s) is(are) supposed to be installed.
- 6.3.5 Reinstall the system according to the installation manual.

7.0 SYSTEM DISCHARGE - RECHARGING CYLINDER AFTER OPERATION



WARNING

DO NOT ENTER A HAZARD AREA WITH AN OPEN FLAME OR LIGHTED CIGARETTE. THE POSSIBLE PRESENCE OF FLAMMABLE VAPORS MAY CAUSE A SPARK, RE-IGNITION OR EXPLOSION.



WARNING

ENSURE FIRE IS COMPLETELY EXTINGUISHED BEFORE VENTILATING THE ENCLOSURE. PERSONNEL MUST USE A BREATHING APPARATUS OR VENTILATE THE ENCLOSURE THOROUGHLY BEFORE ENTERING THE HAZARD AREA.

After system discharge, ventilation of the enclosure must be allowed to ventilate the agent, smoke and harmful by-products from the room produced by post fire to the atmosphere. The hazard area must require an extract ventilation system. Apart from natural ventilation system, mechanical ventilation system is more effective on ventilation and exhaust. Control for ventilation system must be position outside of the enclosure and shall be key operated. In certain situation, ventilation can be provided by having an opened doors and windows.

After system discharge, a qualified fire suppression system maintenance personnel must perform post fire maintenance by checking the hazard area for sources of ignition. Observe all warnings and notices as a safety precaution before entering the hazard area. Inspect system components and nozzle(s) for its functionality and condition.

For cylinder refilling, contact local distributor to arrange for refilling at an authorized UL fill station. The following procedures to enable the refilling of a cylinder that has been discharged.

- Check that the cylinder is empty.
- Remove the electrical point of solenoid discharge valve.
- Recharging Cylinder(s)



WARNING

ONLY QUALIFIED (TRAINED) PERSONNEL SHOULD OPERATE CHARGING EQUIPMENT. EXERCISE EXTREME CARE WHEN WORKING WITH PRESSURE EQUIPMENT TO PREVENT INJURY TO PERSONNEL AND DAMAGE TO PROPERTY, RESULTING FROM CARELESS HANDLING OR POSSIBLE EQUIPMENT FAILURE. PERFORM ALL OPERATIONS IN AN ASSIGNED AREA CLEARED OF ALL UNAUTHORIZED PERSONNEL. MAKE SURE ALL EQUIPMENT IS PROPERLY SECURED AND ALL PERSONNEL SHOULD WEAR PERSONAL PROTECTIVE EQUIPMENT IN THE FILL STATIONS.

7.1 FILLING INERT GAS AGENT

- Cylinders shall be new and have been hydraulic pressure tested.
- The cylinders are factory painted in Red color and fitted with discharge valve prior to filling.
- Filled cylinders to be provided with a cylinder label to indicate the cylinder part number, filled weight and etc.

Note: The cylinder is filled through the valve discharge outlet. Once the filling is completed, Refit the valve outlet with safety cap for safety purpose.

7.2 FILLING INFORMATION

The filling station for LIFECO-01 systems is used to transfer the compressed gas Nitrogen, Argon and Carbon Dioxide into system cylinders. Filling process can only be carried out by trained and authorized person. The filling procedure are as below:

- Issue work order to production person in-charged.
- Relocate the required cylinder to the fill station.
- Visual Inspection shall be done to ensure cylinder is in good condition.
- Attach appropriate filling adaptor to cylinder discharge outlet.
- Key in all the required detailed of the cylinder serial no, filled weight, cylinder size, purchase order, work order, bulk tank serial number, empty cylinder weight into computer.
- Verify agent temperature by measuring cylinder temperature.
- Press start button to start the filling process.
- Disconnect the filling adaptor and refit with valve outlet safety cap.
- Secure cylinder(s) on transport cage or pallets.
- Ship to customer or site as per order.




Figure 7.2.1: IG-01 Pressurized to 200 Bar, 300 Bar at 15°C

8.0 WARRANTY

LIFECO warrants all of the system hardware which is supplies to the customers shall be free from defects in materials and workmanship for a period of one (1) year from the date of installation.

The limited warranty is based upon the customer satisfying the following conditions:

- The system hardware must be supplied, designed, installed and commissioned by LIFECO and its authorized distributor, in accordance with the instructions contained in this manual or other data sheet / information supplied with LIFECO hardware.
- The LIFECO hardware have not been altered or modified.
- Within thirty (30) days after the customer's finding of what the customer believes is a manufacturing defect, the customer must notify LIFECO in writing and ship the hardware to LIFECO or its authorized distributor.
- LIFECO at its option and within 45 days of receipt, will repair, replace or refund the purchase price of that hardware or system found to be defective. Failure of customer to give such written notice and ship the hardware within thirty (30) days shall be deemed absolute and unconditional waiver of any and all claims of the customer arising out of such defect.

The warranty shall not apply in the following circumstances such as:

- The system cylinders filled or refilled by other parties than LIFECO or its authorized distributor approved by LIFECO.
- Any system hardware is found to be non-genuine or supplied other than LIFECO and its distributor.
- System hardware have been modified, serviced, or maintained by other parties than LIFECO and its qualified / certified distributor's technicians.

Limitation of Damages such as:


- LIFECO shall not be liable for incidental consequential, lost profit or other losses arising out of or alleged caused by the use of any LIFECO system hardware.
- LIFECO shall not be liable for, all personal injury and property damage in connected with handling, transportation, possession, or other use or resale of system hardware, whether used alone or in combination with any other products or materials.

9.0 DISCLAIMERS

The contents herein are reasonably believed to be correct at the time of issue but that may not have been independently verified and are subject to change. The information in this manual LFIGMAL-0001 is subject to change without notice. Neither does this manual purport to contain all the information that a qualified clean agent installer or the system user may require. All issues are uncontrolled copies.

10.0 APPENDICES

Appendix A – LIFECO-01 Hydraulic Flow Calculation Program



LIFECO Flow Calculation Software v4.10 (Argon)

File Name: Sample Calculation.FC4

Consolidated Report

Enclosure Report

Elevation: 0 m (relative to sea level)

Atmospheric Correction Factor: 1 (NFPA 2001)

Enclosure 1 Sample Calculation

| | | |
|--|--------------------|-----------------------|
| Enclosure Temperature: | Number of Nozzles: | 4 |
| Minimum: 20.0 C | Width: | 1.00 m |
| Maximum: 35.0 C | Length: | 94.56 m |
| Max. Concentration: 50.65% (At 35.0 C) | Height: | 3.40 m |
| Design Concentration: | Volume: | 321.50 m ³ |
| Adjusted: 48.92 % | Non-permeable: | 0.00 m ³ |
| Minimum: 45.78 % | Total Volume: | 321.50 m ³ |
| Min. Agent Required: 196.80 m ³ | | |
| Adjusted Agent Required: 216.00 m ³ | | |

Calculation Date/Time: Thursday, November 23, 2023, 9:36:19 AM

Copyright (c) Jensen Hughes, Inc.

Key ID: 2049470579

Page: 1 of 7

PART NO : LFIGMAL-0001
REV : 04
DATE : 2024-05



Agent Source Report

Consolidated Report

Agent: Argon

Cylinder Name: 140 L Cylinder - 300 bar

Cylinder Part Number: LF-IG001140300

Agent Per Cylinder: 43.20 m³

Number of Main Cylinders: 5

Number of Reserve Cylinders: 0

Cylinder Empty Weight: 144.00 kg

Weight, All Cylinders + Agent: 1072.70 kg

Floor Area Per Cylinder: 0.08 m²

Floor Loading Per Cylinder: 2388 kg /m²

Calculation Date/Time: Thursday, November 23, 2023, 9:36:19 AM

Copyright (c) Jensen Hughes, Inc.

Key ID: 2049470579

Page: 2 of 7



Consolidated Report

Parts Report

Total Agent Required: 216.00 m³

Cylinder Name: 140 L Cylinder - 300 bar (Part: LF-IG001140300)

Number of Cylinders: 5

| Nozzle | Type | Nozzle Diameter | Nozzle Area | Part Number |
|--------|------|-----------------|------------------------|-------------|
| E1-N1 | 360 | 25 mm | 201.06 mm ² | LF-360IG-25 |
| E1-N2 | 360 | 25 mm | 201.06 mm ² | LF-360IG-25 |
| E1-N3 | 360 | 25 mm | 201.06 mm ² | LF-360IG-25 |
| E1-N4 | 360 | 25 mm | 201.06 mm ² | LF-360IG-25 |

| Nozzle | Drill Diameter | Drill Size |
|--------|----------------|------------|
| E1-N1 | 16.0 mm | 16.0 mm |
| E1-N2 | 16.0 mm | 16.0 mm |
| E1-N3 | 16.0 mm | 16.0 mm |
| E1-N4 | 16.0 mm | 16.0 mm |

| Pipe & Fittings | Type | Diameter | Length | Elbows (90) | Elbows (45) | Tees | Unions |
|-----------------|------|----------|---------|-------------|-------------|------|--------|
| | 80T | 25 mm | 9.50 m | 4 | 0 | 0 | 0 |
| | 80T | 32 mm | 6.00 m | 0 | 0 | 2 | 0 |
| | 80T | 50 mm | 26.50 m | 4 | 0 | 5 | 0 |

| Other Objects | Name | Quantity | Part Number |
|--|------|-----------|-------------|
| Dis Hose W21.8-14TPI x 20mm BSP 450mm 90 Elbow | 5 | LF-DH450E | |
| 12mm Check Valve | 5 | LF-CV | |

System Acceptance Report

System Discharge Time: 70.9 seconds

Calculation Date/Time: Thursday, November 23, 2023, 9:36:19 AM

Copyright (c) Jensen Hughes, Inc.

Key ID: 2049470579

Page: 3 of 7



Consolidated Report

Percent Agent In Pipe: 8.7%

Percent Agent Before First Tee: 7.4%

Enclosure Number: 1

Enclosure Name: Sample Calculation

Minimum Design Concentration: 45.78%

Adjusted Design Concentration: 48.92%

Maximum Design Concentration: 52.00%

Minimum Predicted Concentration: 48.92% (At 20.0 C)

Maximum Predicted Concentration: 50.65% (At 35.0 C)

Maximum Allowed Enclosure Pressure: 500.00 Pa

Estimated Free Vent Area Required: 0.24 m²

Installed Vent Area: 0.00 m²

Predicted Enclosure Pressure: N/A

Maximum Enclosure Flow Rate: 234.9 m³/min

| Nozzle | Minimum Agent Required | Adjusted Agent Required | Predicted Agent Delivered | Nozzle Pressure (Average) |
|--------|------------------------|-------------------------|---------------------------|---------------------------|
| E1-N1 | 49.20 m ³ | 54.00 m ³ | 54.00 m ³ | 17.867 bar |
| E1-N2 | 49.20 m ³ | 54.00 m ³ | 54.00 m ³ | 17.867 bar |
| E1-N3 | 49.20 m ³ | 54.00 m ³ | 54.00 m ³ | 17.867 bar |
| E1-N4 | 49.20 m ³ | 54.00 m ³ | 54.00 m ³ | 17.867 bar |

Calculation Date/Time: Thursday, November 23, 2023, 9:36:19 AM

Copyright (c) Jensen Hughes, Inc.

Key ID: 2049470579

Page: 4 of 7



Consolidated Report

Pipe Network Report

| Description | Pipe Section | Start Node | End Node | Pipe Type | Pipe Diameter | Pipe Length | Union | Total Elevation Change | Total Equivalent Length | Nozzle Name | Nozzle Size | Nozzle Type | Nozzle Area |
|----------------|--------------|------------|----------|-----------|---------------|-------------|-------|------------------------|-------------------------|-------------|-------------|-------------|------------------------|
| Cylinder - On | Man. | 0 | 22 | | 15 mm | 0.03 m | 0 | 0.03 m | 3.66 m | | | | |
| Flex Hose | Man. | 22 | 23 | | 12 mm | 0.45 m | 0 | 0.23 m | 2.72 m | | | | |
| Check Valve -> | Man. | 23 | 24 | | | 0.07 m | 0 | 0.07 m | 0.59 m | | | | |
| Pipe | Man. | 24 | 25 | 80T | 25 mm | 0.30 m | 0 | 0.30 m | 0.30 m | | | | |
| Elbow (90) | Man. | 25 | 26 | 80T | 50 mm | ----- | 0 | ----- | 1.68 m | | | | |
| Pipe | Man. | 26 | 27 | 80T | 50 mm | 0.30 m | 0 | ----- | 0.30 m | | | | |
| Tee | Man. | 27 | 28 | 80T | 50 mm | ----- | 0 | ----- | 1.06 m | | | | |
| Pipe | Man. | 28 | 29 | 80T | 50 mm | 0.30 m | 0 | ----- | 0.30 m | | | | |
| Tee | Man. | 29 | 30 | 80T | 50 mm | ----- | 0 | ----- | 1.06 m | | | | |
| Pipe | Man. | 30 | 31 | 80T | 50 mm | 0.30 m | 0 | ----- | 0.30 m | | | | |
| Tee | Man. | 31 | 32 | 80T | 50 mm | ----- | 0 | ----- | 1.06 m | | | | |
| Pipe | Man. | 32 | 33 | 80T | 50 mm | 0.30 m | 0 | ----- | 0.30 m | | | | |
| Tee | Man. | 33 | 34 | 80T | 50 mm | ----- | 0 | ----- | 1.06 m | | | | |
| Pipe | Man./End | 34 | 35 | 80T | 50 mm | 0.30 m | 0 | ----- | 0.30 m | | | | |
| Elbow (90) | System | 35 | 36 | 80T | 50 mm | ----- | 0 | ----- | 1.68 m | | | | |
| Pipe | System | 36 | 37 | 80T | 50 mm | 1.30 m | 0 | 1.30 m | 1.30 m | | | | |
| Elbow (90) | System | 37 | 38 | 80T | 50 mm | ----- | 0 | ----- | 1.68 m | | | | |
| Pipe | System | 38 | 39 | 80T | 50 mm | 19.50 m | 0 | ----- | 19.50 m | | | | |
| Elbow (90) | System | 39 | 40 | 80T | 50 mm | ----- | 0 | ----- | 1.68 m | | | | |
| Pipe | System | 40 | 41 | 80T | 50 mm | 4.20 m | 0 | ----- | 4.20 m | | | | |
| Tee | System | 41 | 42 | 80T | 32 mm | ----- | 0 | ----- | 2.29 m | | | | |
| Pipe | System | 42 | 43 | 80T | 32 mm | 3.00 m | 0 | ----- | 3.00 m | | | | |
| Tee | System | 43 | 44 | 80T | 25 mm | ----- | 0 | ----- | 1.74 m | | | | |
| Pipe | System | 44 | 45 | 80T | 25 mm | 1.80 m | 0 | ----- | 1.80 m | | | | |
| Elbow (90) | System | 45 | 46 | 80T | 25 mm | ----- | 0 | ----- | 0.85 m | | | | |
| Pipe&Nozzle | System | 46 | 47 | 80T | 25 mm | 0.20 m | 0 | -0.20 m | 0.20 m | E1-N1 | 25 mm | 360 | 201.06 mm ² |
| Tee | System | 47 | 48 | 80T | 25 mm | ----- | 0 | ----- | 1.74 m | | | | |
| Pipe | System | 48 | 49 | 80T | 25 mm | 1.80 m | 0 | ----- | 1.80 m | | | | |
| Elbow (90) | System | 49 | 50 | 80T | 25 mm | ----- | 0 | ----- | 0.85 m | | | | |
| Pipe&Nozzle | System | 50 | 51 | 80T | 25 mm | 0.20 m | 0 | -0.20 m | 0.20 m | E1-N2 | 25 mm | 360 | 201.06 mm ² |
| Tee | System | 51 | 52 | 80T | 32 mm | ----- | 0 | ----- | 2.29 m | | | | |
| Pipe | System | 52 | 53 | 80T | 32 mm | 3.00 m | 0 | ----- | 3.00 m | | | | |

Key ID: 2049470579

Page: 5 of 7



Consolidated Report


| Description | Pipe Section | Start Node | End Node | Pipe Type | Pipe Diameter | Pipe Length | Union | Total Elevation Change | Total Equivalent Length | Nozzle Name | Nozzle Size | Nozzle Type | Nozzle Area |
|----------------|--------------|------------|----------|-----------|---------------|-------------|-------|------------------------|-------------------------|-------------|-------------|-------------|------------------------|
| Tee | System | 53 | 54 | 80T | 25 mm | ----- | 0 | ----- | 1.74 m | | | | |
| Pipe | System | 54 | 55 | 80T | 25 mm | 1.80 m | 0 | ----- | 1.80 m | | | | |
| Elbow (90) | System | 55 | 56 | 80T | 25 mm | ----- | 0 | ----- | 0.85 m | | | | |
| Pipe&Nozzle | System | 56 | 57 | 80T | 25 mm | 0.20 m | 0 | -0.20 m | 0.20 m | E1-N3 | 25 mm | 360 | 201.06 mm ² |
| Tee | System | 53 | 58 | 80T | 25 mm | ----- | 0 | ----- | 1.74 m | | | | |
| Pipe | System | 58 | 59 | 80T | 25 mm | 1.80 m | 0 | ----- | 1.80 m | | | | |
| Elbow (90) | System | 59 | 60 | 80T | 25 mm | ----- | 0 | ----- | 0.85 m | | | | |
| Pipe&Nozzle | System | 60 | 61 | 80T | 25 mm | 0.20 m | 0 | -0.20 m | 0.20 m | E1-N4 | 25 mm | 360 | 201.06 mm ² |
| Tee | Man. | 5 | 34 | 80T | 50 mm | ----- | 0 | ----- | 3.41 m | | | | |
| Pipe | Man. | 4 | 5 | 80T | 25 mm | 0.30 m | 0 | 0.30 m | 0.30 m | | | | |
| Check Valve -> | Man. | 3 | 4 | | | 0.07 m | 0 | 0.07 m | 0.59 m | | | | |
| Flex Hose | Man. | 2 | 3 | | | 0.45 m | 0 | 0.23 m | 2.72 m | | | | |
| Cylinder - On | Man. | 0 | 2 | | 15 mm | 0.03 m | 0 | 0.03 m | 3.66 m | | | | |
| Tee | Man. | 10 | 32 | 80T | 50 mm | ----- | 0 | ----- | 3.41 m | | | | |
| Pipe | Man. | 9 | 10 | 80T | 25 mm | 0.30 m | 0 | 0.30 m | 0.30 m | | | | |
| Check Valve -> | Man. | 8 | 9 | | | 0.07 m | 0 | 0.07 m | 0.59 m | | | | |
| Flex Hose | Man. | 7 | 8 | | | 0.45 m | 0 | 0.23 m | 2.72 m | | | | |
| Cylinder - On | Man. | 0 | 7 | | 15 mm | 0.03 m | 0 | 0.03 m | 3.66 m | | | | |
| Tee | Man. | 15 | 30 | 80T | 50 mm | ----- | 0 | ----- | 3.41 m | | | | |
| Pipe | Man. | 14 | 15 | 80T | 25 mm | 0.30 m | 0 | 0.30 m | 0.30 m | | | | |
| Check Valve -> | Man. | 13 | 14 | | | 0.07 m | 0 | 0.07 m | 0.59 m | | | | |
| Flex Hose | Man. | 12 | 13 | | | 0.45 m | 0 | 0.23 m | 2.72 m | | | | |
| Cylinder - On | Man. | 0 | 12 | | 15 mm | 0.03 m | 0 | 0.03 m | 3.66 m | | | | |
| Tee | Man. | 20 | 28 | 80T | 50 mm | ----- | 0 | ----- | 3.41 m | | | | |
| Pipe | Man. | 19 | 20 | 80T | 25 mm | 0.30 m | 0 | 0.30 m | 0.30 m | | | | |
| Check Valve -> | Man. | 18 | 19 | | | 0.07 m | 0 | 0.07 m | 0.59 m | | | | |
| Flex Hose | Man. | 17 | 18 | | | 0.45 m | 0 | 0.23 m | 2.72 m | | | | |
| Cylinder - On | Man. | 0 | 17 | | 15 mm | 0.03 m | 0 | 0.03 m | 3.66 m | | | | |

Key ID: 2049470579

Page: 6 of 7



Consolidated Report



Key ID: 2049470579

Page: 7 of 7

Appendix B – SAFETY DATA SHEET



Safety Data Sheet

Section 1 – Chemical Product and Company Identification

| | |
|------------------|---|
| Product Name | IG-01 Gas Suppression System |
| Agent | Argon, Compressed Gas |
| Chemical Name | Argon |
| Product Use | Fire extinguishing agent |
| Supplier | Lichfield Fire & Safety Equipment CO LTD |
| Supplier Address | Edmund House 12-22 Newhall Street, Birmingham, B3 3AS United Kingdom |
| Email | sales@lifeco-uk.com |
| Telephone | +44 (0) 1902 798 706 |
| Fax | +44 (0) 1902 798 679 |

Section 2 – Hazard Identification

OSHA/HCS status This material is considered hazardous by the OSHA Hazard Communication Standard (29 CFR 1910.1200)

Classification of the substance or mixture H280 – Compressed Gas

Hazard pictograms



Signal word Warning

Hazard statements H280: Contains gas under pressure; may explode if heated

Precautionary statements Read and follow all Security Data Sheets (SDS) before use. Read labels before use. Keep out of reach of children. If medical advice is needed, hold the container or label the product in your hand. Close the valve after each use and when the cylinder is empty. Do not open the valves until they are fitted to the equipment provided for use. Use a backflow prevention device in the pipe. Only use material that is compatible with the material.
Use and store outside or in a well ventilated area.
Protect from the sun. Protect from sunlight when ambient temperature exceed 52°C/125°F.
Asphyxiant in high concentrations.



Safety Data Sheet

Section 3 – Composition/Information on Ingredients

| Ingredient name | CAS No. | %(weight) |
|-----------------|-----------|-----------|
| Argon | 7440-37-1 | ≥99.995 |

Section 4 – First Aid Measures

| | |
|------------|---|
| Inhalation | Remove victim to uncontaminated area wearing self-contained breathing apparatus. Keep victim warm and rested. Call a doctor. Apply artificial respiration if breathing stopped. |
| Skin | Wash exposed skin with soap and water. |
| Eyes | Immediately flush with large amounts of water for at least 15 minutes. Get medical attention if irritation occurs. |

Most important symptoms and effects, both acute and delayed

| | |
|--------------|--|
| Eye contact | Contact with high pressured gas may cause burns or frostbite |
| Inhalation | May cause asphyxiation |
| Skin contact | Contact with high pressured gas may cause burns or frostbite |
| Frostbite | Rewarm the contact area and get medical attention |

Section 5 – Fire Fighting Measures

| | |
|---|--|
| Extinguishing media | Water spray or fog. |
| Unsuitable extinguishing media | Do not use water jet to extinguish. |
| Special fire fighting procedures | In case of fire: Stop leak if safe to do so. Continue water spray from protected position until container stays cool. Use extinguishants to contain the fire. Isolate the source of the fire or let it burn out. |
| Special protective equipment for firefighters | Use self-contained breathing apparatus (SCBA) in confined space. Standard EN 137 – Self-contained open-circuit compressed air breathing apparatus with full face mask 2T |

Section 6 – Accidental Release Measures

| | |
|---|--|
| Personal precautions, protective equipment and emergency procedures | Evacuate area. Provide adequate ventilation. Prevent from entering sewers, basements and workpits, or any place where its accumulation can be dangerous. Wear self-contained breathing apparatus when entering area unless atmosphere is proved to be safe. Guideline EN 137 Respiratory protective devices - Self-contained open-circuit compressed air breathing apparatus with full face mask - Requirements, testing, marking. |
| Environmental precautions | Prevent further leakage or spillage if safe to do so. |
| Methods and material for containment and cleaning up | Provide adequate ventilation. |



Safety Data Sheet

Section 7 – Handling and Storage

Handling

Only experienced and properly instructed persons should handle gases under pressure. Use only properly specified equipment which is suitable for this product, its supply pressure and temperature. Refer to supplier's handling instructions. The substance must be handled in accordance with good industrial hygiene and safety procedures. Protect containers from physical damage; do not drag, roll, slide or drop. Do not remove or deface labels provided by the supplier for the identification of the container contents. When moving containers, even for short distances, use appropriate equipment e.g. trolley, hand truck, fork truck etc. Secure cylinders in an upright position at all times, close all valves when not in use. Provide adequate ventilation. Suck back of water into the container must be prevented. Do not allow backfeed into the container. Avoid suckback of water, acid and alkalis. Keep container below 50°C in a well-ventilated place. Observe all regulations and local requirements regarding storage of containers. When using do not eat, drink or smoke. Store in accordance with local/regional/national/international regulations. Never use direct flame or electrical heating devices to raise the pressure of a container. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. Damaged valves should be reported immediately to the supplier. Close container valve after each use and when empty, even if still connected to equipment. Never attempt to repair or modify container valves or safety relief devices. Replace valve outlet caps or plugs and container caps where supplied as soon as container is disconnected from equipment. Keep container valve outlets clean and free from contaminants particularly oil and water. If user experiences any difficulty operating container valve discontinue use and contact supplier. Never attempt to transfer gases from one container to another. Container valve guards or caps should be in place.

Storage

Containers should not be stored in conditions likely to encourage corrosion. Stored containers should be periodically checked for general conditions and leakage. Container valve guards or caps should be in place. Store containers in location free from fire risk and away from sources of heat and ignition. Keep away from combustible material.

Section 8 –Exposure Controls/Personal Protection

Appropriate engineering controls

Consider a work permit system e.g. for maintenance activities. controls Ensure adequate air ventilation. Provide adequate ventilation, including appropriate local extraction, to ensure that the defined occupational exposure limit is not exceeded. Oxygen detectors should be used when asphyxiating gases may be released. Systems under pressure should be regularly checked for leakages. Preferably use permanent leak tight connections (e.g. welded pipes). Do not eat, drink or smoke when using the product.

Personal protective equipment

Skin Protection

Wear working gloves while handling containers. Standard EN 388

Eye Protection

Wear safety glasses with side shields. Standard EN 166

Other

Wear safety shoes while handling containers. Standard EN ISO 20345



Safety Data Sheet

Section 9 – Physical and Chemical Properties

| | | |
|---------------------------|---|--|
| Physical state | : | Gas |
| Colour | : | Colourless |
| Odour | : | Odourless |
| Melting point | : | -189°C (-308°F) |
| Boiling point | : | -186°C (-303 °F) |
| Critical temperature | : | -122°C (-188°F) |
| Flammability (solid, gas) | : | Non flammable |
| Vapour Density | : | 1.38 (Air = 1) |
| Solubility in Water | : | 67.3 mg/l |
| Other information | : | Gas/vapour heavier than air. May accumulate in confined spaces, particularly at or below ground level. |
| Molecular weight | : | 40.0 g/mol |
| Molecular formula | : | Ar |

Section 10 – Stability and Reactivity

| | |
|------------|---|
| Reactivity | No reactivity hazard other than the effects described in sub-section below. |
|------------|---|

| | |
|------------------------------------|--|
| Chemical stability | Stable under normal conditions. |
| Possibility of hazardous reactions | No known hazardous reactions |
| Incompatible materials | No reaction with any common materials in dry or wet conditions. |
| Hazardous decomposition products | Under normal conditions of storage and use, hazardous decomposition products should not be produced. |

Section 11 – Toxicological Information

No known toxicological effects from this product.

Section 12 – Ecological Information

No known ecological damage caused by this product.

Section 13 – Disposal Considerations

| | |
|--------------------|---|
| General : | Do not discharge into any place where its accumulation could be dangerous. To atmosphere in a well-ventilated place. Contact supplier if guidance is required. |
| Disposal methods : | Refer to the EIGA code of practice (Doc.30 "Disposal of Gases", downloadable at http://www.eiga.org) for more guidance on suitable disposal methods. Dispose of container via supplier only. Discharge, treatment, or disposal may be subject to national, state, or local laws. |



Safety Data Sheet

Section 14—Transport Information

UN Number : UN1006
UN Proper Shipping Name : ARGON, COMPRESSED
Hazard label (DOT) : 2.2 (Non-flammable gas)



Section 15—Regulatory Information

National Regulations : Occupational Safety and Health Act 1994 and relevant regulations:
• Occupational Safety and Health (Classification, Labeling and Safety Data Sheet of Hazardous Chemicals) Regulations 2013.
• Occupational Safety and Health (Use and Standards of Exposure of Chemicals Hazardous to Health) Regulations 2000.
• Environment Quality Act 1974 & regulations:
• Environment Quality (Clean Air) Regulations 2014.
• Environmental Quality (Scheduled Wastes) Regulations 2005.

Section 16 – Other Information

NFPA Ratings : Health: 0 Fire: 0 Instability: 0 Other: SA
Hazard Scale: 0 = Minimal 1 = Slight 2 = Moderate 3 = Serious 4 = Severe
Training information : Users of breathing apparatus must be trained. The hazard of asphyxiation is often overlooked and must be stressed during operator training. Ensure operators understand the hazards.
Other information : Before using this product in any new process or experiment, a thorough material compatibility and safety study should be carried out. Ensure adequate air ventilation. Ensure all national/local regulations are observed. Whilst proper care has been taken in the preparation of this document, no liability for injury or damage resulting from its use can be accepted.



Safety Data Sheet

Disclaimer

In accordance with good practices of personal cleanliness and hygiene handle with the care and avoid unnecessary contact with this product. This information is being supplied to you under OSHA Hazard Communication Standard 29 CFR 1910.1200 and is offered in good faith as typical values and not as a product specification. The information contained herein is based on the data available to us and is believed to be true and accurate. No warranty expressed or implied regarding the accuracy of this data. The hazards connected with the use of the material or the results to be obtained from the use thereof are made. LIFECO assumes no responsibility for damage or injury from the use of the product described herein

Appendix C – Safety Bulletins

LIFECO-01 Engineered fire suppression system uses pressurized cylinders, therefore, personnel responsible for fire suppression systems must be aware of the dangers associated with the improper handling, installation and maintenance of the system equipment.

Fire suppression system service personnel must be thoroughly trained in the proper handling, installation and maintenance of LIFECO-01 equipment and follow the instructions of this manual. Warnings, cautions and important notes written in this manual are to be adhered to at all times. Failure to do so may result in serious injury to personnel.

Important safety memos before handling a cylinder.

- PRESSURIZED CYLINDERS ARE EXTREMELY HAZARDOUS AND IF NOT HANDLED PROPERLY ARE CAPABLE OF VIOLENT DISCHARGE. THIS MAY RESULT IN SERIOUS BODILY INJURY, DEATH AND PROPERTY DAMAGE.
- Before handling LIFECO-01 cylinder(s), all personnel must be thoroughly trained in the safe handling of the cylinder(s) as well as in the proper procedures for installation, removal, filling and connection of other components, such as an electrical actuator(s) to ensure **fault light doesn't show up** and connecting the discharge pipe to the valve outlet.
- READ, UNDERSTAND and ALWAYS FOLLOW this operation and maintenance manual.
Safe cylinder handling procedures
- Cylinder(s) must be shipped compactly in the upright/vertical position and must be properly secured in place. Cylinder(s) must neither be rolled, dragged/slid, nor allowed to be slid from tailgates of moving vehicles. A suitable hand truck, forklift truck, roll platform or a similar transport equipment or vehicle must be used.
- Cylinder(s) must not be dropped or permitted to strike violently against each other or other surfaces.
- Cylinder(s) must be stored in a standing upright position where they are not likely to be knocked over and they must be secured. Cylinder(s) should not be positioned in direct sunlight, area exceeding 55°C (131°F) or below -20°C (-4 °F).

Appendix D – LIFECO-01 System Components and their Part Numbers

| Components Description | Part Number |
|---|-----------------|
| LIFECO-UK IG01 80L 200bar Assembly c/w Solenoid valve | LF-IG00180200S |
| LIFECO-UK IG01 80L 300bar Assembly c/w Solenoid valve | LF-IG00180300S |
| LIFECO-UK IG01 140L 200bar Assembly c/w Solenoid valve | LF-IG001140200S |
| LIFECO-UK IG01 140L 300bar Assembly c/w Solenoid valve | LF-IG001140300S |
| LIFECO-UK IG01 80L 200bar Assembly c/w Discharge valve | LF-IG00180200 |
| LIFECO-UK IG01 80L 300bar Assembly c/w Discharge valve | LF-IG00180300 |
| LIFECO-UK IG01 140L 200bar Assembly c/w Discharge valve | LF-IG001140200 |
| LIFECO-UK IG01 140L 300bar Assembly c/w Discharge valve | LF-IG001140300 |
| IG 4L Pilot cylinder 200bar Assembly | LF-IGPC4 |
| IG 10L Pilot Cylinder 200bar Assembly | LF-IGPC10 |
| IG Discharge Valve (W21.8-14TPI) 200bar | LF-IGDV200 |
| IG Discharge Valve (W21.8-14TPI) 300bar | LF-IGDV300 |
| IG Solenoid discharge valve (W21.8-14TPI) 200bar | LF-IGEASV200 |
| IG Solenoid discharge valve (W21.8-14TPI) 300bar | LF-IGEASV300 |
| IG Manual actuator for Solenoid valve | LF-COMA |
| IG Pneumatic Manual actuator | LF-COMPA |
| IG Pneumatic Manual actuator for Solenoid valve | LF-COMPA/1 |
| IG Pneumatic actuator 20bar | LF-COPA |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 250mm Straight | LF-DH250S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 300mm Straight | LF-DH300S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 350mm Straight | LF-DH350S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 400mm Straight | LF-DH400S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 450mm Straight | LF-DH450S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 500mm Straight | LF-DH500S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 550mm Straight | LF-DH550S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 600mm Straight | LF-DH600S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 650mm Straight | LF-DH650S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 700mm Straight | LF-DH700S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 750mm Straight | LF-DH750S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 800mm Straight | LF-DH800S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 850mm Straight | LF-DH850S |

| | |
|--|------------|
| IG Discharge Hose W21.8-14TPI x 20mm BSP 900mm Straight | LF-DH900S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 950mm Straight | LF-DH950S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 1000mm Straight | LF-DH1000S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 1100mm Straight | LF-DH1100S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 1200mm Straight | LF-DH1200S |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 250mm 90°Elbow | LF-DH250E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 300mm 90°Elbow | LF-DH300E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 350mm 90°Elbow | LF-DH350E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 400mm 90°Elbow | LF-DH400E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 450mm 90°Elbow | LF-DH450E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 500mm 90°Elbow | LF-DH500E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 550mm 90°Elbow | LF-DH550E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 600mm 90°Elbow | LF-DH600E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 650mm 90°Elbow | LF-DH650E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 700mm 90°Elbow | LF-DH700E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 750mm 90°Elbow | LF-DH750E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 800mm 90°Elbow | LF-DH800E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 850mm 90°Elbow | LF-DH850E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 900mm 90°Elbow | LF-DH900E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 950mm 90°Elbow | LF-DH950E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 1000mm 90°Elbow | LF-DH1000E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 1100mm 90°Elbow | LF-DH1100E |
| IG Discharge Hose W21.8-14TPI x 20mm BSP 1200mm 90°Elbow | LF-DH1200E |
| IG Pilot Hose M12-1.5 x 350mm | LF-PH350 |
| IG Pilot Hose M12-1.5 x 450mm | LF-PH450 |
| IG Pilot Hose adaptor | LF-PHA |
| IG Pilot Hose Tee connector (swivel on side) | LF-SORS |
| IG Pilot Hose Elbow | LF-PVE |
| IG Pilot Hose Tee connector (swivel on run) | LF-SORT |
| IG Pilot Valve adaptor | LF-PVA |
| IG bleed valve | LF-BVPL |
| IG Check valve | LF-CV |
| IG Constant pressure regulator | LF-PR |

| | |
|-------------------------------------|--------------|
| IG Pilot Line Check Valve | LF-CVPL |
| IG Nozzle 10mm 360deg BSP | LF-360IG-10 |
| IG Nozzle 15mm 360deg BSP | LF-360IG-15 |
| IG Nozzle 20mm 360deg BSP | LF-360IG-20 |
| IG Nozzle 25mm 360deg BSP | LF-360IG-25 |
| IG Nozzle 32mm 360deg BSP | LF-360IG-32 |
| IG Nozzle 40mm 360deg BSP | LF-360IG-40 |
| IG Nozzle 50mm 360deg BSP | LF-360IG-50 |
| IG Nozzle 10mm 180deg BSP | LF-180IG-10 |
| IG Nozzle 15mm 180deg BSP | LF-180IG-15 |
| IG Nozzle 20mm 180deg BSP | LF-180IG-20 |
| IG Nozzle 25mm 180deg BSP | LF-180IG-25 |
| IG Nozzle 32mm 180deg BSP | LF-180IG-32 |
| IG Nozzle 40mm 180deg BSP | LF-180IG-40 |
| IG Nozzle 50mm 180deg BSP | LF-180IG-50 |
| IG Pressure gauge 300bar NO | LF-PGLPS3 |
| IG Pressure gauge 200bar NO | LF-PGLPS4 |
| IG Pressure gauge 300bar NC | LF-PGLPS5 |
| IG Pressure gauge 200bar NC | LF-PGLPS6 |
| IG 80L Bracket (Dia:360mm) | LF- CB-80 |
| IG 140L Bracket (Dia:474mm) | LF- CB-140 |
| IG 4L/10L Pilot Bracket (Dia:148mm) | LF- CBP |
| 80L Manifold 20mm 2 Port | LF-2COM20-80 |
| 80L Manifold 20mm 3 Port | LF-3COM20-80 |
| 80L Manifold 25mm 2 Port | LF-2COM25-80 |
| 80L Manifold 25mm 3 Port | LF-3COM25-80 |
| 80L Manifold 25mm 4 Port | LF-4COM25-80 |
| 80L Manifold 25mm 5 Port | LF-5COM25-80 |
| 80L Manifold 32mm 2 Port | LF-2COM32-80 |
| 80L Manifold 32mm 3 Port | LF-3COM32-80 |
| 80L Manifold 32mm 4 Port | LF-4COM32-80 |
| 80L Manifold 32mm 5 Port | LF-5COM32-80 |
| 80L Manifold 32mm 6 Port | LF-6COM32-80 |
| 80L Manifold 32mm 7 Port | LF-7COM32-80 |

| | |
|---------------------------|---------------|
| 80L Manifold 40mm 2 Port | LF-2COM40-80 |
| 80L Manifold 40mm 3 Port | LF-3COM40-80 |
| 80L Manifold 40mm 4 Port | LF-4COM40-80 |
| 80L Manifold 40mm 5 Port | LF-5COM40-80 |
| 80L Manifold 40mm 6 Port | LF-6COM40-80 |
| 80L Manifold 40mm 7 Port | LF-7COM40-80 |
| 80L Manifold 40mm 8 Port | LF-8COM40-80 |
| 80L Manifold 50mm 2 Port | LF-2COM50-80 |
| 80L Manifold 50mm 3 Port | LF-3COM50-80 |
| 80L Manifold 50mm 4 Port | LF-4COM50-80 |
| 80L Manifold 50mm 5 Port | LF-5COM50-80 |
| 80L Manifold 50mm 6 Port | LF-6COM50-80 |
| 80L Manifold 50mm 7 Port | LF-7COM50-80 |
| 80L Manifold 50mm 8 Port | LF-8COM50-80 |
| 80L Manifold 65mm 3 Port | LF-3COM65-80 |
| 80L Manifold 65mm 4 Port | LF-4COM65-80 |
| 80L Manifold 65mm 5 Port | LF-5COM65-80 |
| 80L Manifold 65mm 6 Port | LF-6COM65-80 |
| 80L Manifold 65mm 7 Port | LF-7COM65-80 |
| 80L Manifold 65mm 8 Port | LF-8COM65-80 |
| 80L Manifold 80mm 3 Port | LF-3COM80-80 |
| 80L Manifold 80mm 4 Port | LF-4COM80-80 |
| 80L Manifold 80mm 5 Port | LF-5COM80-80 |
| 80L Manifold 80mm 6 Port | LF-6COM80-80 |
| 80L Manifold 80mm 7 Port | LF-7COM80-80 |
| 80L Manifold 80mm 8 Port | LF-8COM80-80 |
| 80L Manifold 100mm 5 Port | LF-5COM100-80 |
| 80L Manifold 100mm 6 Port | LF-6COM100-80 |
| 80L Manifold 100mm 7 Port | LF-7COM100-80 |
| 80L Manifold 100mm 8 Port | LF-8COM100-80 |
| 140L Manifold 25mm 2 Port | LF-2COM25-140 |
| 140L Manifold 25mm 3 Port | LF-3COM25-140 |
| 140L Manifold 32mm 2 Port | LF-2COM32-140 |
| 140L Manifold 32mm 3 Port | LF-3COM32-140 |

| | |
|--|-----------------|
| 140L Manifold 32mm 4 Port | LF-4COM32-140 |
| 140L Manifold 32mm 5 Port | LF-5COM32-140 |
| 140L Manifold 40mm 2 Port | LF-2COM40-140 |
| 140L Manifold 40mm 3 Port | LF-3COM40-140 |
| 140L Manifold 40mm 4 Port | LF-4COM40-140 |
| 140L Manifold 40mm 5 Port | LF-5COM40-140 |
| 140L Manifold 40mm 6 Port | LF-6COM40-140 |
| 140L Manifold 50mm 2 Port | LF-2COM50-140 |
| 140L Manifold 50mm 3 Port | LF-3COM50-140 |
| 140L Manifold 50mm 4 Port | LF-4COM50-140 |
| 140L Manifold 50mm 5 Port | LF-5COM50-140 |
| 140L Manifold 50mm 6 Port | LF-6COM50-140 |
| 140L Manifold 50mm 7 Port | LF-7COM50-140 |
| 140L Manifold 50mm 8 Port | LF-8COM50-140 |
| 140L Manifold 65mm 3 Port | LF-3COM65-140 |
| 140L Manifold 65mm 4 Port | LF-4COM65-140 |
| 140L Manifold 65mm 5 Port | LF-5COM65-140 |
| 140L Manifold 65mm 6 Port | LF-6COM65-140 |
| 140L Manifold 65mm 7 Port | LF-7COM65-140 |
| 140L Manifold 65mm 8 Port | LF-8COM65-140 |
| 140L Manifold 80mm 3 Port | LF-3COM80-140 |
| 140L Manifold 80mm 4 Port | LF-4COM80-140 |
| 140L Manifold 80mm 5 Port | LF-5COM80-140 |
| 140L Manifold 80mm 6 Port | LF-6COM80-140 |
| 140L Manifold 80mm 7 Port | LF-7COM80-140 |
| 140L Manifold 80mm 8 Port | LF-8COM80-140 |
| 140L Manifold 100mm 7 Port | LF-7COM100-140 |
| 140L Manifold 100mm 8 Port | LF-8COM100-140 |
| 80L Manifold 50mm 6 port - Double Row | LF-DR6COM50-80 |
| 80L Manifold 65mm 6 port - Double Row | LF-DR6COM65-80 |
| 80L Manifold 80mm 6 port - Double Row | LF-DR6COM80-80 |
| 80L Manifold 100mm 6 port - Double Row | LF-DR6COM100-80 |
| 140L Manifold 50mm 6 port - Double Row | LF-DR6COM50-140 |
| 140L Manifold 65mm 6 port - Double Row | LF-DR6COM65-140 |

| | |
|--|------------------|
| 140L Manifold 80mm 6 port - Double Row | LF-DR6COM80-140 |
| 140L Manifold 100mm 6 port - Double Row | LF-DR6COM100-140 |
| IG Selector valve 20mm BSP | LF-DIV20-BSP |
| IG Selector valve 20mm NPT | LF-DIV20-NPT |
| IG Selector valve 25mm BSP | LF-DIV25-BSP |
| IG Selector valve 25mm NPT | LF-DIV25-NPT |
| IG Selector valve 32mm BSP | LF-DIV32-BSP |
| IG Selector valve 32mm NPT | LF-DIV32-NPT |
| IG Selector valve 40mm BSP | LF-DIV40-BSP |
| IG Selector valve 40mm NPT | LF-DIV40-NPT |
| IG Selector valve 50mm BSP | LF-DIV50-BSP |
| IG Selector valve 50mm NPT | LF-DIV50-NPT |
| IG Selector valve ISO Flange 65mm | LF-DIV65-ISO |
| IG Selector valve ISO Flange 80mm | LF-DIV80-ISO |
| IG Selector valve ISO Flange 100mm | LF-DIV100-ISO |
| IG Selector valve DIN Flange 65mm | LF-DIV65-DIN |
| IG Selector valve DIN Flange 80mm | LF-DIV80-DIN |
| IG Selector valve DIN Flange 100mm | LF-DIV100-DIN |
| Pilot Cylinder label | LF-CL3 |
| LIFECO-01 Cylinder label (252.8mm x 190mm) | LF-CL5 |
| Discharge Pressure Switch | LF-DPS |

Appendix E – Maintenance Program

Inspection File - Maintenance of Fire Suppression Systems

| System Service Provider | | | | |
|--|--|-----------------|-----|----|
| Service Provider: | Project No: _____ | | | |
| Address: | Purchase Order: _____ | | | |
| City: | Installation Date: _____ | | | |
| Postcode: | Inspection Date: _____ | | | |
| Telephone: | Clean Agent Systems: _____ | | | |
| Fax: | _____ | | | |
| Installation Location | | | | |
| Installation Site Address: | _____ | | | |
| City: | _____ | | | |
| Postcode: | _____ | | | |
| Telephone: | _____ | | | |
| Fax: | _____ | | | |
| Site Official Representative: | _____ | | | |
| Period of Service (*** Please circle where appropriate) | | | | |
| Monthly | Semi-Annual | Annual | | |
| 1. Protected Enclosure: | | | | |
| Inspect the project details / data of the protected enclosure to ensure the system suitability for the fire protection, no alterations or modifications with respect to the previous service report. | | | | |
| Property owner / contractor shall provide the required details prior to inspection. | | | | |
| *** Every NO answer shall be explained in detail and indicate so under observations. | | | | |
| No | Description | Findings | | |
| | | YES | N/A | NO |
| 1.1 | Dimension of protected enclosure. | | | |
| 1.2 | Area occupied by persons. | | | |
| 1.3 | Modification on protected enclosure. | | | |
| 1.4 | Protected enclosure equipped with automatic disconnection during system discharge. | | | |
| 1.5 | Any previously noted deficiencies / past defects have been corrected. | | | |
| Observations: | | | | |

Inspection File - Maintenance of Fire Suppression Systems

2. Agent Storage Area

Inspect and check if there are any changes to the approved installation and general condition of hardware installed. Ensure the system is isolated electrically and mechanically, remove manual actuator, electrical actuator, manifold (if applicable) discharge hose and piping away from cylinder valves. Immediately fit the safety cap onto the cylinder valves outlet to prevent accidental discharge.

*** Every NO answer shall be explained in detail and indicate so under observations.

Observations:

Inspection File - Maintenance of Fire Suppression Systems

3. Distribution / Piping System

Pipe system carrying agent from cylinders to distribution nozzles inside the hazard area. Inspect and check if the distribution / piping system has undergone any changes / modification since previous inspection. The piping used shall be schedule 40 pipes.

*** Every NO answer shall be explained in detail and indicate so under observations.

| No | Description | Findings | | |
|-----|---|----------|-----|----|
| | | YES | N/A | NO |
| 3.1 | Pipe length and diameter have not undergone changes from previous project inspection. | | | |
| 3.2 | Are pipes free from mechanical damages along its length? | | | |
| 3.3 | Piping layout as per initial approved system design. | | | |
| 3.4 | PTFE tape is used to apply on the pipe male thread. | | | |
| 3.5 | Is dirt trap install to the end of each pipe runs? | | | |
| 3.6 | Are the threaded pipes used for the distribution system? | | | |
| 3.7 | Supports used are those specified in the project. | | | |
| 3.8 | Any previous record of deficiencies have been corrected. | | | |

Observations:

4. Discharge Nozzles

Visualize inspect and check the condition of discharge nozzles or if they have been undergone modification.

*** Every NO answer shall be explained in detail and indicate so under observations.

| No | Description | Findings | | |
|-----|--|----------|-----|----|
| | | YES | N/A | NO |
| 4.1 | Quantity of discharge nozzles installed in accordance with the system design approved for earlier design and installation. | | | |
| 4.2 | Discharge nozzles installed conform with model of those specified in system design approved for earlier design and installation. | | | |
| 4.3 | Discharge nozzle condition clean (no foreign material), no debris and physical damages. | | | |
| 4.4 | Discharge nozzle orientation as per earlier design. | | | |
| 4.5 | Discharge nozzle is free from obstacles and any projecting parts. | | | |
| 4.6 | Discharge nozzle has not undergone any modifications. | | | |

Observations: